

Wonderware DAServer for Omron FINS Ethernet User's Guide

Invensys Systems, Inc.

Revision B

Last Revision: 10/26/07



Copyright

© 2007 Invensys Systems, Inc. All Rights Reserved.

All rights reserved. No part of this documentation shall be reproduced, stored in a retrieval system, or transmitted by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Invensys Systems, Inc. No copyright or patent liability is assumed with respect to the use of the information contained herein. Although every precaution has been taken in the preparation of this documentation, the publisher and the author assume no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained herein.

The information in this documentation is subject to change without notice and does not represent a commitment on the part of Invensys Systems, Inc. The software described in this documentation is furnished under a license or nondisclosure agreement. This software may be used or copied only in accordance with the terms of these agreements.

Invensys Systems, Inc.
26561 Rancho Parkway South
Lake Forest, CA 92630 U.S.A.
(949) 727-3200

<http://www.wonderware.com>

For comments or suggestions about the product documentation, send an e-mail message to productdocs@wonderware.com.

Trademarks

All terms mentioned in this documentation that are known to be trademarks or service marks have been appropriately capitalized. Invensys Systems, Inc. cannot attest to the accuracy of this information. Use of a term in this documentation should not be regarded as affecting the validity of any trademark or service mark.

Alarm Logger, ActiveFactory, ArcestrA, Avantis, DBDump, DBLoad, DT Analyst, FactoryFocus, FactoryOffice, FactorySuite, FactorySuite A², InBatch, InControl, IndustrialRAD, IndustrialSQL Server, InTouch, MaintenanceSuite, MuniSuite, QI Analyst, SCADAAlarm, SCADASuite, SuiteLink, SuiteVoyager, WindowMaker, WindowViewer, Wonderware, and Wonderware Logger are trademarks of Invensys plc, its subsidiaries and affiliates. All other brands may be trademarks of their respective owners.

Contents

	Welcome.....	7
	Documentation Conventions.....	7
	Technical Support.....	8
Chapter 1	Getting Started	9
	Before You Begin	10
	Supported Client Protocols	10
	Supported Device Protocols	11
	Supported Devices	11
	Supported Topologies.....	11
	Windows Firewall Considerations	12
	Checklist for Setting up a DAServer	14
	Finding Your DAServer in the SMC.....	15
Chapter 2	Managing Channels	17
	Adding a Channel.....	18
	Renaming a Channel.....	18
	Setting Channel Parameters	18
	Selecting the Adapter.....	19
	Setting the Communications Port	19
	Setting the Write/Read Duty Cycle	20
	Deleting a Channel.....	21

Chapter 3	Managing Devices	23
	Adding a Device.....	23
	Renaming a Device.....	24
	Setting the General Parameters.....	24
	Assigning a PLC Model to the Device	24
	Setting the ID Parameter	25
	Setting the Protocol Parameters	26
	Setting the Communication Timeouts	26
	Setting the Request Size	27
	Setting the FINS Network Configuration.....	28
	Setting Single and Multiple Network Levels.....	29
	Matching Device and PLC Addresses	29
	Deleting a Device.....	30
Chapter 4	Managing Device Groups	31
	Adding a Device Group	31
	Renaming a Device Group	32
	Setting Device Group Data	33
	Deleting a Device Group	34
Chapter 5	Managing Device Items	35
	Creating Aliases for Item References.....	36
	Renaming a Device Item	37
	Deleting a Device Item.....	37
	Setting the Item Reference	38
	Exporting and Importing CSV Files.....	38
	Clearing All Device Item Names	39
Chapter 6	Managing Your DAServer	41
	Configuring the DAServer as Service	42
	Configuring the DAServer as Not a Service	42
	Archiving Configuration Sets	42
	Activating/Deactivating the DAServer	44
	In-Proc/Out-of-Proc	45
	Hot Configuration	45
	Demo Mode	46
Chapter 7	Accessing the Data in Your DAServer	47
	Accessing Data Using OPC.....	48

Accessing Data Using DDE/SuiteLink.....	48
Chapter 8 Item Reference Descriptions.....	49
Standard System Items.....	49
Global System Item.....	50
Device-Group-Specific System Items	51
Device-Specific System Items	55
Supported Data Types.....	58
Format and Syntax.....	59
Unsigned/Signed Format	59
BCD Format.....	60
Long Format (Signed/BCD)	60
Floating Point Format (IEEE)	60
ASCII Strings Format.....	61
Alternate ASCII String Format.....	62
Bit Access	63
Array Access	63
Using 32-bit Values	63
Address Descriptions.....	64
C200 Address Descriptions	64
CV500 Address Descriptions	70
CV1000 and CV2000 Address Descriptions	74
CVM1-CPU01 Address Descriptions	80
CVM1-CPU11 Address Descriptions	84
CVM1-CPU21 Address Descriptions	88
CS1 Address Descriptions.....	95
CJ1 Address Descriptions	101
Chapter 9 Troubleshooting	107
Troubleshooting with Windows Tools	107
Troubleshooting with the DAServer Manager.....	108
Finding Version Information	108
Using the Wonderware Log Viewer	108
Basic Log Flags.....	109
DAServer Log Flags	110
DAServer-Device Interface Log Flags	111
Error Message Descriptions.....	112
Index	117

Welcome

The Wonderware DAServer for Omron Fins Ethernet is a Microsoft Windows application that allows client applications access to the SYSMAC C/CV/CS1/CJ1-Series Programmable Logic Controllers (PLCs).

Documentation Conventions

This documentation uses the following conventions:

Convention	Used for
Initial Capitals	Paths and filenames.
Bold	Menus, commands, dialog box names, and dialog box options.
Monospace	Code samples and display text.

Technical Support

Wonderware Technical Support offers a variety of support options to answer any questions on Wonderware products and their implementation.

Before you contact Technical Support, refer to the relevant section(s) in this documentation for a possible solution to any problem you have. If you need to contact technical support for help, have the following information ready:

- The type and version of the operating system you are using. For example, Microsoft Windows XP, SP1.
- Details of how to recreate the problem.
- The exact wording of the error messages you saw.
- Any relevant output listing from the Log Viewer or any other diagnostic applications.
- Details of what you did to try to solve the problem(s) and your results.

If known, the Wonderware Technical Support case number assigned to your problem, if this is an ongoing problem.

Chapter 1

Getting Started

The DAServer is one component of a software system that connects your software application with information on the factory floor.

This DAServer documentation covers only the information you need to configure and run the DAServer component. See the documentation that comes with the related components for details on their operation. You can find installation instructions in a help file on the distribution CD.

You use the DAServer Manager to configure, activate, and troubleshoot the DAServer. The DAServer Manager is located in the System Management Console (SMC). For more information, see Finding Your DAServer in the SMC on page 15.

This documentation describes some of the features of the DAServer Manager. See the *DAServer Manager User's Guide* to find more information on:

- Global parameters
- Configuration sets
- Time zone features
- Icon definitions
- Activation/deactivation
- Configuring as a service
- Importing/exporting device items
- Standard diagnostics

You can troubleshoot problems with the DASServer using the ArcestrA Log Viewer, a snap-in to the SMC. See the Log Viewer help file to find information on:

- Viewing error messages.
- Determining which messages are shown.
- Bookmarking error messages.

You may also be able to troubleshoot problems using your client application, such as the Wonderware InTouch HMI software. The client application can use system device items to determine the status of nodes and the values of some parameters. For more information on system items, see Standard System Items on page 49.

Before You Begin

Before configuring the DASServer, verify the following items:

- A PC is set up with the necessary network cards, and connected to the necessary networks.
- The Windows administration account is created or identified.
- The DASServer and any other Wonderware software such as the DASServer Manager is installed with the proper licenses. For more information, see the License Utility documentation on the distribution CD.
- The client software is installed.
- The device(s) is/are connected (networked) and, if necessary, programmed.

Before configuring the DASServer, you should know:

- The device network configuration and addresses.
- Which data items are needed for the client application.
- The device name/topic name/group name.
- The desired update intervals.

Supported Client Protocols

Client applications connect to the DASServer using OPC and DDE/SuiteLink. For more information, see the Protocols guide that is included with the distribution CD.

Supported Device Protocols

The DAServer connects to Omron PLCs on a FINS network using UDP/IP.

Supported Devices

You can use the following Omron devices with this DAServer:


- C200
- CV500
- CV1000
- CV2000
- CVM1-CPU01
- CVM1-CPU11
- CVM1-CPU21
- CS1
- CJ1

Supported Topologies

This DAServer communicates with FINS compatible devices on an Ethernet network. If a device is a destination node, it processes the FINS command. If a device is not the destination node, it relays the message on to the destination node.

Both the routing PLC(s) and target PLC must support FINS.

FINS allows up to three network levels. A direct connection between a computer and a PLC through Host Link is not considered a network level.



Windows Firewall Considerations

If the DAServer runs on a computer with a firewall enabled, a list of application names or port numbers must be put in the firewall exception list so the DAServer can function correctly.

By default, the DAServer installation program makes the required entries in the firewall exception list. If you do not want the installation program to make entries in the firewall exception list, you must add the entries manually. For information on how to make entries in the firewall exception list, see your firewall or Windows security documentation.

You must ensure the following applications are in the firewall exception list. The applications can be added automatically during installation, or you can add them manually on the computer running the DAServer:

- DASOMFINSEnet.exe
- aaLogger.exe
- DASAgent.exe
- dllhost.exe
- mmc.exe
- OPCEnum.exe

- Slssvc.exe

You must ensure the following port numbers are in the firewall exception list. The port numbers can be added automatically during installation, or you can add them manually on the computer running the DAServer:

- 5413 - TCP port for slssvc.exe
- 445 - TCP port for file and printer sharing
- 135 - TCP port for DCOM
- 9600 a UDP port for DASOMFINSEnet
- UDP ports configured in the PLC for use with this DAServer, other than the standard port 9600.

Put the following applications in the firewall exception list on the computer where the DAServer Manager is installed:

- aaLogger.exe
- dllhost.exe
- mmc.exe

Put the following port numbers in the firewall exception list on the computer where the DAServer Manager is installed:

- 445 - TCP port for file and printer sharing
- 135 - TCP port for DCOM

Un-installing the DAServer does not remove the firewall exception list entries. You must delete the firewall exception list entries manually. For more information on how to do this, see your firewall or Windows security documentation.

Checklist for Setting up a DAServer

If you are setting up a DAServer for the first time, perform the following tasks in the order listed:

- 1 Review the items described in Before You Begin on page 10.
- 2 Locate the DAServer in the System Management Console (SMC). See Finding Your DAServer in the SMC on page 15.
- 3 Configure the global parameters. See the *DAServer Manager User's Guide*.
- 4 Add a channel. See Adding a Channel on page 18.
- 5 Set the channel parameters. See Setting Channel Parameters on page 18.
- 6 Add a device. See Adding a Device on page 23.
- 7 Set the device communication parameters. See Setting the General Parameters on page 24.
- 8 Add one or more device groups. See Adding a Device Group on page 31.
- 9 Add device items. See Managing Device Items on page 35.
- 10 Activate the DAServer. See Activating/Deactivating the DAServer on page 44.
- 11 Access data from the client, including specifying device item references. See Accessing the Data in Your DAServer on page 47 and Setting the Item Reference on page 38.
- 12 Troubleshoot any problems. See Troubleshooting on page 107.

Finding Your DAServer in the SMC

Each DAServer is identified by a unique name. The name for the Wonderware DAServer for Omron Fins Ethernet is ArchestrA.DASOMFINSEnet.1. On the computer where the DAServer is installed, it can be found in the local node of the default group of the DAServer Manager.

You do not need to install the DAServer Manager on the same computer as the DAServer. When you access the DAServer remotely, you will not find the DAServer node under the local node. You must locate and identify the DAServer on a computer in one of the node groups.

To find the DAServer

- 1 On the Start menu, click **Programs**. Navigate to the Wonderware folder that contains the System Management Console and then click **System Management Console**.
- 2 In the **System Management Console**, expand **DAServer Manager**.
- 3 Locate the group with the node **ArchestrA.DASOMFINSEnet.1**

Chapter 2

Managing Channels

Channels are the communications link between the DAServer and devices. You must create a channel node before you can add device nodes. You can create up to 100 channels.

Before you add a channel, you need to organize and define the topology of the devices being connected.

When you add a channel, the DAServer gives the channel a default name. You may change this name to a name that represents how the network is organized. Channel names cannot have spaces.

A channel has three parameters:

- The adapter card the channel uses to communicate with devices
- The communications port
- The write/read duty cycle


Adding a Channel

The first step in specifying the network between the DAServer and a device is to add a channel. After you add a channel to the hierarchy, you can add device nodes.

To add a channel

- 1 In the DAServer Manager, navigate to the **Configuration** node.
 - a Expand **DAServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
 - b Expand the DAServer.
- 2 Right-click **Configuration** and click **Add Channel Object**.

The console tree shows a new node with a default channel name selected.



- 3 Type a new name and then press Enter.

Renaming a Channel

Changing the channel name prevents clients from registering data using the old name. Data for existing queries is set to bad quality. Try not to make changes to parameters like the channel name after you develop a large client application.

To change an existing channel name

- 1 In the DAServer Manager, navigate to the channel.
 - a Expand **DAServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
 - b Expand the DAServer and then expand **Configuration**.
- 2 Right-click the channel and click **Rename**.
- 3 Type the new name and press Enter.

Setting Channel Parameters

Channel parameters include the adapter, the communications port, and the write/read duty cycle.

Selecting the Adapter

If devices are connected to multiple adapters, specify which adapter a channel uses, because devices are tied to channels. Use **Default** if you have a single active network connection. If you have multiple network cards, select the card connected to the subnetwork on which the PLCs are located. You can assign an adapter to multiple channels. However, a channel can have only one adapter.


Spreading your devices over several channels can improve DAServer performance. The performance benefit depends on the message traffic on your network.

The recommended configuration is one Device (PLC) per channel.

The network adapter specifies the Network Interface Card (NIC) the DAServer should use when accessing devices on the channel.

You can change the adapter parameter when the DAServer is active. Changing the adapter parameter when the DAServer is active can disrupt network communications.

To select the adapter

- 1 In the DAServer Manager, navigate to the channel.
 - a Expand **DAServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
 - b Expand the DAServer and then expand **Configuration**.
- 2 Select the channel. The right pane shows the channel parameters.
- 3 In the **Adapter** list, click the appropriate adapter.
-  4 Click the **Save** icon.

Setting the Communications Port

The FINS network protocol requires that all devices on an Ethernet network use the same port number to send and receive data. Valid port numbers range from 1 to 65535, with a default of 9600.

For best communication performance, create multiple channels, and assign each channel a unique port number.

Note The same FINS/UDP port must be configured in the PLC connected to this channel.

For example:


- **Channel1.device1** communicates on Port 9601

- **Channel2.device2** communicates on Port 9602

Note Configure all devices (PLCs) connected to a channel with the same FINS/UDP Port as the channel.

Multihoming the computer running the DASOMFINSEthernet server can enable communication with multiple PLCs configured on different channels using the same UDP port (for example default 9600).

To set the port number

- 1 In the DAServer Manager, navigate to the channel.
 - a Expand **DAServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
 - b Expand the DAServer and then expand **Configuration**.
- 2 Select the channel. The right pane shows the channel parameters.
- 3 In the **Port** box, enter a port number.
-  4 Click the **Save** icon.

Setting the Write/Read Duty Cycle

The duty cycle allows you to control the ratio of write operations to read operations. The ratio is always based on one read for every 1 to 10 writes. The default duty cycle is 10. This means 10 writes occur for each read operation.

If your application is doing a large number of continuous writes and you need to ensure that reads are processed in a timely fashion, you may want to reduce the duty cycle. If you set the duty cycle to 1, a single read operation occurs for every write operation. If there are no write operations to perform, reads are processed as needed.

This write/read duty cycle overrides the transaction to subscription ratio global parameter.

To set the write/read duty cycle

- 1 In the DAServer Manager, navigate to the channel.
 - a Expand **DAServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
 - b Expand the DAServer and then expand **Configuration**.
- 2 Select the channel. The right pane shows the channel parameters.
- 3 In the **Write/Read Duty Cycle** box, type or select a number.
- 4 Click the **Save** icon.

Deleting a Channel

If your computer hardware or the network connection between the computer and devices changes, you need to delete a channel.

When you delete a channel, all nodes below the channel are also deleted. If a client application requests new data from a deleted channel or from a node on a deleted channel, the request is rejected. Data for existing queries is set to bad quality.

To delete a channel

- 1 In the DAServer Manager, navigate to the channel.
 - a Expand **DAServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
 - b Expand the DAServer and then expand **Configuration**.
- 2 Right-click the channel and click **Delete**.
- 3 Read the warning and then click **Yes**. The channel node and all nodes (devices) below it in the hierarchy are deleted.

Chapter 3

Managing Devices


A device communicates with a DAServer and may connect to other devices or I/O points. You set the communication parameters the DAServer uses to communicate with a device.

Adding a Device

You must add a device to the hierarchy before creating device items. A device name cannot contain spaces.

To add a device

- 1 In the DAServer Manager, navigate to the channel node.
 - a Expand **DAServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
 - b Expand the DAServer and then expand **Configuration**.
- 2 Right-click the channel node and click **Add Device Object**. The console tree shows a new node with a default device name selected.



- 3 Type a name and press Enter.

Renaming a Device

You can change the device name while the DAServer is active. After the device name is changed, client applications using the old name cannot register data with the DAServer. Data for existing queries is set to bad quality. Try not to make changes to the device name after you develop a large client application.

The device name cannot contain spaces.

To change an existing device name

- 1 In the DAServer Manager, navigate to the device.
 - a Expand **DAServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
 - b Expand the DAServer, expand **Configuration**, and then expand the channel.
- 2 Right-click the device whose name you want to change and then click **Rename**.
- 3 Type a name and press Enter.

Setting the General Parameters

You can set the general parameters by selecting the Controller model, setting the ID Parameter, and enabling data collection.

Assigning a PLC Model to the Device


You can only change the model selection if there are currently no client applications connected to the device.

To assign a PLC model to a device

- 1 In the DAServer Manager, navigate to the device.
 - a Expand **DAServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
 - b Expand the DAServer, expand **Configuration**, and then expand the channel.
- 2 Select the device.
- 3 In the right pane, click the **Parameters** tab. This is shown with the device name followed by the word “Parameters.”



The image shows a screenshot of a software interface. On the left, the text 'Model:' is displayed. To its right is a dropdown menu with a white background and a thin border. The menu is currently open, showing the text 'C200' in a black font. A small downward-pointing arrow is visible on the right side of the dropdown box.

- 4 In the **Model** list, select the model.
-  5 Click the **Save** icon.


Setting the ID Parameter

You specify the IP address of the device if it is on the same Ethernet network as the computer running the DAServer. Otherwise, you specify the IP address of the relay device, which must be on the same Ethernet network as the computer running the DAServer.


For more information, see your OMRON FINS documentation.

To set the ID

- 1 In the DAServer navigate to the device.
 - a Expand **DAServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
 - b Expand the DAServer, expand **Configuration**, and then expand the channel.
- 2 Select the device.
- 3 In the right pane, click the **Parameters** tab. The tab appears with the device name followed by the word “Parameters.”



The screenshot shows a light beige background with the text 'ID:' on the left and a white text input box on the right. The input box contains the IP address '255.255.255.255'.

- 4 In the ID box, type the network address.
-  5 Click the **Save** icon.

Setting the Protocol Parameters

The device protocol parameters include the communications timeouts and the request size parameter.


Setting the Communication Timeouts

You can set three communication timeouts: connect timeout, reply timeout, and fail after.

- The connect timeout is the time that the DAServer waits for a connection to be made with a device. Depending on the network load, the connect time varies with each connection attempt. The default setting is 3 seconds. The valid range is 1 to 60 seconds. For heavily loaded or slow networks, set the connection time out to a larger value.
- The reply timeout is the time the DAServer waits on a response from the device before giving up and going on to the next request. Longer timeouts only affect performance if a device is not responding.
- The fail after parameter determines how many times the DAServer sends a communications request before the request fails and the device is in error. The valid range is 1 to 10 retries. The default is 3 retries.

To set the communication time out values

- 1 In the DAServer Manager, navigate to the device.
 - a Expand **DAServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
 - b Expand the DAServer, expand **Configuration**, and then expand the channel.
- 2 Select the device.
- 3 Click the **Parameters** tab. The tab appears with the device name followed by the word “Parameters.”



The screenshot shows a window titled "Protocol" with three rows of settings, each with a numeric input field and a unit label:

Parameter	Value	Unit
Connection timeout:	3	seconds
Reply timeout:	1000	milliseconds
Fail after:	3	successive timeouts

- 4 In the **Protocol** area, type or select values for the **Connect timeout**, **Reply timeout** and **Fail after** boxes.
- 5 Click the **Save** icon.

Setting the Request Size


You can set the number of bytes that are returned from a device at a single time. If the DAServer is reading data from a large number of contiguous addresses, it is probably advantageous to use a large request size.

You can configure the request size as: 32, 64, 128, 256, or 512 bytes. The default value is 512 bytes.

To set the request size

- 1 In the DAServer Manager navigate to the device.
 - a Expand **DAServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
 - b Expand the **DAServer**, expand **Configuration**, and then expand the channel.
- 2 Select the device.
- 3 In the right pane select the **Parameters** tab. The tab appears with the device name followed by the word “Parameters.”

Request size: bytes

- 4 In the **Request size** list, enter or select a number.
-  5 Click the **Save** icon.

Setting the FINS Network Configuration

The FINS network configuration includes six parameters of of FINS message headers. These parameters are:

- Source network address number. This the network address number of the source device, the computer running the DAServer. This is sometimes called SNA in Omron FINS documentation. Valid numbers range from **0** to **127**.
- Source node number. This the node number of the computer running the DAServer. This is sometimes called SA1 in Omron FINS documentation. Valid numbers range from **0** to **254**.

The number configured on the Device Configuration face plate must be unique and should be the host part of the PC's IP address. If two DAServers access the same PLC, the source node number must also be unique.

If the destination PLC is configured to use automatic address generation, this number must be the host number portion of the host computer's IP address. For example, if the host computer has an IP of 111.222.333.123, and the subnet mask is 255.255.255.000, the source node number is 123.

If the destination PLC is configured to use an address table, the table must have an entry for the host computer's IP. The node number in this table entry must match the source node number entered here.

Tip For network card redundancy when using a PC with Dual NICs, configure the PLC for Auto-Dynamic Address Table generation, and configure the DAServer Adapter as **Default**. In case the primary network connection fails, the PLC can resume communication with the DAServer via the second network connection. For more information, see *Selecting the Adapter* on page 19.

- Source unit number. This the unit number of the computer running the DAServer. This is sometimes called SA2 in OMRON FINS documentation. The DAServer always sets this parameter to zero.
- Destination network address number. This the network address number of the destination device. This is sometimes called DNA in Omron FINS documentation. Valid numbers range from **0** to **127**.
- Destination Node number. This the node number of the destination device. This is sometimes called DA1 in Omron FINS documentation. Valid numbers range from **0** to **254**.

- **Destination Unit number.** This is the unit number of the destination device. This is sometimes called DA2 in OMRON FINS documentation. Valid numbers range from 0 to 255. The default is zero.

Setting Single and Multiple Network Levels

The default value for the network parameter in each case is zero. Zero represents the local network.


Using zero is convenient if there is only one network level. When you use multiple network levels, you must specify the actual network number (1 - 127) to avoid routing ambiguities.

Matching Device and PLC Addresses


Pay particular attention to the FINS network and node numbers configured for each device and the IP address calculation method used by the target PLCs. Inconsistent values result in communications problems. For more information, see the OMRON FINS documentation.

To set the FINS network parameters

- 1 In the DAServer Manager, navigate to the device.
 - a Expand **DAServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
 - b Expand the DAServer, expand **Configuration**, and then expand the channel.
- 2 Select the device.
- 3 In the right pane select the **Parameters** tab. The tab appears with the device name followed by the word “Parameters.”



Fins Network Configuration	
Source Network Address Number:	<input type="text" value="0"/>
Source Node Number:	<input type="text" value="0"/>
Destination Network Address Number:	<input type="text" value="0"/>
Destination Nodes Number:	<input type="text" value="0"/>
Destination Unit Number:	<input type="text" value="0"/>

- 4 In the **FINS Network Configuration** area, enter a number in each field.
- 5  Click the **Save** icon.

Deleting a Device

Deleting a device removes the node and all device group and device item information. Deleting a device is not reversible. If you make a mistake, you must re-enter the device information.

New requests for data that use the deleted device name are rejected. Data for existing queries is set to bad quality.

To delete a device

- 1 In the DAServer Manager, navigate to the device.
 - a Expand **DAServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
 - b Expand the DAServer, expand **Configuration**, and then expand the channel.
- 2 Right-click the device and then click **Delete**.
- 3 Read the warning and then click **Yes**.

Chapter 4

Managing Device Groups

Device groups are labels used by client applications when accessing the DAServer. The device group update interval determines how often the DAServer polls the device and sends data to the client application. If you configure multiple device groups with different update intervals, the client application can receive data at various intervals.

Small update intervals mean fast turnaround for data changes and a high overhead because a large amount of data is moving. Large update intervals mean slow turn around for data changes and a low overhead because not as much data is being passed to the client application.

For DDE/SuiteLink clients, the device group is the same as the DDE/SuiteLink topic. DDE/SuiteLink clients require that at least one device group be created for each device.

For OPC clients, the device group equals the OPC access path. The DAServer has a default device group for each device, and this device group cannot be deleted. If you are using OPC client applications, creating a device group is optional.


Adding a Device Group

Device groups allow you to specify an update interval for a set of device items. The device group does not contain any device items. The linkage is made when the client makes a request.

To add a device group

- 1 In the DAServer Manager, navigate to the device.
 - a Expand **DAServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
 - b Expand the DAServer, expand **Configuration**, and then expand the channel.
- 2 Select the device.
- 3 In the right pane, click the **Device Groups** tab.
- 4 Right-click the column field, and click **Add**. A **Name** field appears with a default name.

Name	Update Interval (ms)
Topic_0	1000

- 5 Type a name and press Enter. The **Update Interval** field defaults to 1000. The unit is in milliseconds (ms). A device group is added.
- 6  Click the **Save** icon.

Renaming a Device Group


Changing the name of an existing device group requires that any client queries using the device group must be changed. Requests for data accepted by the DAServer before the change are not affected.

To change a device group name

- 1 In the DAServer Manager, navigate to the device.
 - a Expand **DAServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
 - b Expand the DAServer, expand **Configuration**, and then expand the channel.
- 2 Select the device.
- 3 Click the **Device Groups** tab.
- 4 Move the pointer over the name or the box containing the name to be changed.

- 5 Right-click the name and then click **Rename**. The name is selected.

New_Device_000 Parameters	
Device Groups	
Device Items	
Name	Update Interval (ms)
Topic 0	1000

- 6 Type a name and press Enter.
-  7 Click the **Save** icon.


Setting Device Group Data

The device group data consists of one item, the update interval. The update interval specifies the time period in milliseconds between DAServer reads of the device memory. You can specify a number between 0 and 2147483646 (596.52 hours).

To set the update interval

- 1 In the DAServer Manager, navigate to the device.
 - a Expand **DAServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
 - b Expand the DAServer, expand **Configuration**, and then expand the channel.
- 2 Select the device.
- 3 In the right pane, click the **Device Groups** tab.
- 4 Right-click the interval and click **Modify Update Interval**. The current update interval is selected.


Update Interval (ms)
1000

- 5 Type an interval and press Enter.
-  6 Click the **Save** icon.

Deleting a Device Group

When you delete a device group, the quality of items being accessed using the device group changes to BAD. The DASServer rejects new requests for data using the device group.

To delete a device group

- 1 In the DASServer Manager, navigate to the device.
 - a Expand **DASServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
 - b Expand the DASServer, expand **Configuration**, and then expand the channel.
- 2 Select the device.
- 3 In the right pane, click the **Device Groups** tab.
- 4 Right-click the group to be deleted and click **Delete**.
- 5 Read the warning and then click **Yes**.
-  6 Click the **Save** icon.

Chapter 5

Managing Device Items

Defining device items provides a more user-friendly way to name data in the device. Defining device items is optional. Use device items to access data in the DAServer and devices connected to the DAServer. Device items consist of two pieces: a name and an item reference. You can specify either from your client.

The device item name is an alternative name for the item reference. It is an “alias” or a label for the data in the device. You can use this label instead of the item reference when you create the client application.

The item reference identifies data in the device. The item reference is a PLC memory reference. Each device’s memory reference can have a different format. For more information, see [Item Reference Descriptions](#) on page 49.

The actual item reference can be entered as the device item name. In this case, the item reference value can be left empty.

To provide diagnostic and operational information, the DAServer has several system items that do not access data in a device. They are grouped by function:

- Global system items
- Device-group-specific system items
- Device-specific system items

For more information, see [Standard System Items](#) on page 49.

Device item names defined in the DAServer show up as OPC browsable items.

You can add device items while the DAServer is active, and these new items are immediately available to client applications.

You can make changes to items while the DAServer is active. Changes take effect immediately. OPC clients that are already connected to the item are not affected until they release and re-acquire the item.

For detailed formats for specifying item references, see Item Reference Descriptions on page 49.


For information on how to subscribe to data items, see Accessing the Data in Your DAServer on page 47.

Creating Aliases for Item References

The device item name is an alias for the item reference. Device item names can be 256 characters long. Long names may be more explanatory, but your client application may have limited screen space.

To set a device item name

- 1 In the DAServer Manager, navigate to the device.
 - a Expand **DAServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
 - b Expand the DAServer, expand **Configuration**, and then expand the channel.
- 2 Select the device.
- 3 In the right pane, click the **Device Items** tab.
- 4 Right-click the column and click **Add**. A **Name** field is selected with a default name.




- 5 Type the name and press Enter.
- 6 Click the **Save** icon.

Renaming a Device Item

Changing a device item name affects new client requests for data. Requests for data already accepted by the DASServer are not affected.


To change a device item name

- 1 In the DASServer Manager, navigate to the device.
 - a Expand **DASServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
 - b Expand the DASServer, expand **Configuration**, and then expand the channel.
- 2 Select the device.
- 3 In the right pane, click the **Device Items** tab.
- 4 Right-click the device item name, and click **Rename**.
- 5 Type the new name and press Enter.
-  6 Click the **Save** icon.

Deleting a Device Item

Deleting a device item name affects new client requests for data. Requests for data already accepted by the DASServer are not affected.

To delete a device item name

- 1 In the DASServer Manager, navigate to the device.
 - a Expand **DASServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
 - b Expand the DASServer, expand **Configuration**, and then expand the channel.
- 2 Select the device.
- 3 In the right pane, click the **Device Items** tab.
- 4 Right-click the item to be deleted and click **Delete**.
- 5 Read the warning and click **Yes**.
-  6 Click the **Save** icon.

Setting the Item Reference


You must know which memory locations you need and the memory location attributes before entering item references in the DAServer.

For more information, see *Format and Syntax* on page 59.


For tables that list the options for each device type, see *Item Reference Descriptions* on page 49. In this case device type does not refer to the model of PLC.

To set an item reference

- 1 In the DAServer Manager, navigate to the device.
 - a Expand **DAServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
 - b Expand the DAServer, expand **Configuration**, and then expand the channel.
- 2 Select the device.
- 3 Click the **Device Items** tab.
- 4 Right-click the **Item Reference** field to be set and click **Rename**.



Name	Item Reference
Item_0	D1000

- 5 Type the item reference and press Enter.
- 6  Click the **Save** icon.

Exporting and Importing CSV Files

To help you manage item references (tags) and device item names outside of the DAServer Manager, the DAServer supports importing and exporting device item data in a comma separated value (CSV) file. The CSV functions are only available when a device items tab is selected.

To export a device item list

- 1 In the DAServer Manager, navigate to the device.
 - a Expand **DAServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
 - b Expand the DAServer, expand **Configuration**, and then expand the channel.
- 2 Select the device.
- 3 In the right pane, click the **Device Items** tab.

- 4 Right-click the columns field and click **Export**.
- 5 In the **Save As** dialog box, type a file name, select a directory, and click **Save**.


To import a device item list

- 1 In the DAServer Manager, navigate to the device.
 - a Expand **DAServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
 - b Expand the **DAServer**, expand **Configuration**, and then expand the channel.
- 2 Select the device.
- 3 In the right pane, click the **Device Items** tab.
- 4 Right-click the columns field and click **Import**.
- 5 In the **Open** dialog box, find the file containing the items to be imported, and press **Open**. Items contained in the file are now listed on the **Device Items** tab.

Clearing All Device Item Names

You can delete all device items for a device.

To clear all device item names

- 1 In the DAServer Manager, navigate to the device.
 - a Expand **DAServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
 - b Expand the **DAServer**, expand **Configuration**, and then expand the channel.
- 2 Select the device.
- 3 In the right pane, click the **Device Items** tab.
- 4 Right-click the columns field and click **Clear All**.
- 5 Read the warning and click **Yes**.
-  6 Click the **Save** icon.

Chapter 6

Managing Your DAServer

After you configure the DAServer, there are two steps to take before you can access data with your client application.

The first step is to determine what kind of client applications are to be used with this DAServer. If any of your client applications use DDE/SuiteLink, you must configure the DAServer as a service. If only OPC client applications will be used, you can configure the DAServer as a service or as not a service.

The last step is to activate the DAServer. Some client applications can programatically activate the DAServer. If you configure the DAServer as an automatic service, the DAServer is started and activated when the computer on which the DAServer is installed starts up. If you configure the DAServer as a manual service, the DAServer is not started when the computer starts up. Instead, it is started upon the first connection from an OPC client or when activated from the DAServer Manager.

After a DAServer is running as an auto or manual service, it stays running until explicitly stopped in the DAServer Manager or the computer shuts down.

Configuring the DAServer as Service

To support DDE/SuiteLink clients, the DAServer must be configured as a service.

To configure the DAServer as a service

- 1 In the DAServer Manager, navigate to the DAServer.
 - Expand **DAServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
- 2 Right-click **Archestra.DASOMFINSEnet.1** and then click **Configure As Service**.
- 3 Click either **Auto Service** or **Manual Service**.
- 4 Read the warning message and click **Yes**.

Configuring the DAServer as Not a Service

The DAServer can only be set to run as not a service when the DAServer is in the deactivated state.

To configure the DAServer as not a service

- 1 In the DAServer Manager, navigate to the DAServer.
 - Expand **DAServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
- 2 Right-click **Archestra.DASOMFINSEnet.1** and then click **Configure As Service**.
- 3 Click **Not a Service**.
- 4 Read the warning message and click **Yes**.

Archiving Configuration Sets

A configuration set includes the DAServer's global parameters; each channel and its parameters; and each device and its parameters, device groups, and device items. It lets you manage the settings of different DAServer configurations.

The DAServer contains a default configuration set named **DASOMFINSEnet**. You cannot delete the default configuration set.

You can create multiple configuration sets and switch between them. Archiving, clearing, and switching configuration sets can only be done when the DAServer is deactivated.

Before you create a configuration set, verify that you have saved any changes you made to the global parameters. If you change a parameter and then immediately create a configuration set, the original parameter value is saved as part of the configuration set, not the changed value.

 To save a global parameter, click the **Save** icon.

To archive a configuration set

- 1 In the DASServer Manager, navigate to the configuration node.
 - a Expand **DASServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
 - b Expand the DASServer.
- 2 Click **Configuration**.
- 3 Right-click and click **Archive Configuration Set**.
- 4 In the dialog box, type the configuration set name, and click **Archive**. All the current configuration values are saved to the set.

After you archive at least one configuration set, you can select it for use.

To select a configuration set


- 1 In the DASServer Manager, navigate to the configuration node.
 - a Expand **DASServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
 - b Expand the DASServer.
- 2 Click **Configuration**.
- 3 Right-click, point to **Use Another Configuration Set**, then click the desired name.

To change the parameter values saved in a configuration set, make sure the desired configuration set is shown, then follow this procedure.

To change the parameter values in a configuration set

- 1 In the DASServer Manager, navigate to the configuration node.
 - a Expand **DASServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
 - b Expand the DASServer.

- 2 Click **Configuration**.
- 3 Change the parameters that you want to change.

-  4 Click the **Save** icon.

Clearing a configuration set returns the parameters to their default values.

To clear a configuration set

- 1 In the DAServer Manager, navigate to the configuration node.
 - a Expand **DAServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
 - b Expand the DAServer.
- 2 Click **Configuration**.
- 3 Right-click, move the mouse over **Clear Configuration Set**, then left click.
- 4 Read the warning message, then click **Yes**. The parameters are set to the default values.

To delete a configuration set

- 1 In the DAServer Manager, navigate to the configuration node.
 - a Expand **DAServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
 - b Expand the DAServer.
- 2 Click **Configuration**.
- 3 Right-click **Configuration**, point to **Delete Configuration Set** and select the configuration set to delete.
- 4 Read the warning message, then click **Yes**.

Activating/Deactivating the DAServer

When you activate the DAServer, it starts communicating and accepting requests from client applications. If a DAServer is configured as an automatic service, the DAServer is started and activated when the computer starts up. Also, a DAServer can be activated by the an OPC client connection request.

To activate the DAServer

- 1 In the DAServer Manager, navigate to the DAServer.
 - Expand **DAServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
- 2 Right-click **ArchestrA.DASOMFINSEnet.1** and then click **Activate Server**.

Deactivating your DAServer stops it from communicating with client applications.

A DAServer with active OPC clients does not stop until the last OPC client shuts down.

To deactivate the DAServer

- 1 In the DAServer Manager, navigate to the DAServer.
 - Expand **DAServer Manager**, expand the node group, and then expand **Local** or the remote computer name.
- 2 Right-click **ArchestrA.DASOMFINSEnet.1** and then click **Deactivate Server**.
- 3 Read the warning message and click **Yes**.

In-Proc/Out-of-Proc

The DAServer can run as a stand-alone process (out-of-proc) or as part of the client process (in-proc).

When the DAServer is running out-of-proc, it supports requests from both DDE/SuiteLink and OPC client applications. When the DAServer is running in-proc, it only supports OPC client applications.

If the DAServer is running as a service, the icon on the DAServer node in the SMC is yellow. If the DAServer is running as not a service, the icon is white. For more information, see the *DAServer Manager User's Guide*.

Hot Configuration

The DAServer allows certain configuration parameters to be changed while the DAServer is active. See the sections about the specific parameters for limitations or constraints.

Demo Mode

You can install the DAServer without a license. The DAServer runs without a license in Demo mode for 120 minutes. While in demo mode the DAServer checks for a license every 30 seconds. When the 120 minutes expires:

- the DAServer stops updating items.
- all non-system items have a Bad quality status.
- new items are rejected.

After the 120 minutes the DAServer checks for a license every thirty seconds. If a license is not found, the DAServer logs a warning.

You can use the `$$SYS$Licensed` system item to check the status of your license. This item returns true if the proper license is found or the DAServer is in demo mode (the 120 minutes), otherwise, it returns false.

After the DAServer finds a valid license, it logs a message, stops looking for a license, and begins running normally. For more information, see the *License Utility User Guide*.

Chapter 7

Accessing the Data in Your DAServer

Client applications read and write to data items that are internal to the DAServer, as well as to the items located in the devices. Client application communication with the DAServer is done using either the OPC, or DDE/SuiteLink protocols. The client application may or may not be on the same computer as the DAServer.

You do not need to create device items in the DAServer for your OPC client application.

For information on how to specify item references, see [Format and Syntax](#) on page 59. For information on specific address formats, see [Address Descriptions](#) on page 64.

Accessing Data Using OPC

To connect to the DAServer with an OPC client application, be aware of the following six parameters:

- **node name:** The computer name identifying the node where the DAServer is located. Only required for remote access.
- **program name:** ArcestrA.DASOMFINSEnet.1
- **group name:** An OPC group defined and created by the client. The DAServer device group is used as the OPC access path.
- **device group:** A device group as defined on the DAServer. If omitted, the default device group is assumed.
- **link name:** The hierarchy of nodes names, from the channel node to the device node, separated by delimiters.
- **item name:** The specific data element. This can be the device item name or the item reference.

The combination of the link name and item name form the OPC data path for any OPC client to access DAServer data.

If the item specified is not valid for the device location, the DAServer does not accept the item. The DAServer returns bad quality and generates an error message in the logger.

Accessing Data Using DDE/SuiteLink

The DDE/SuiteLink address has four fields:

- **node name:** The computer name identifying the node where the DAServer is located. Only required for remote access.
- **application name:** DASOMFINSEnet
- **topic name:** A device group defined for the device.
- **item name:** The specific data element. This can be the device item name or the item reference.

The DDE/SuiteLink topic is the equivalent to the device group.

Chapter 8

Item Reference Descriptions

You use item references to access system items and read and write data from devices.

Standard System Items

System items provide you easy access to DASServer status and diagnostics information. Client applications can read data from them just like ordinary items. However, in most cases the system item values are not directly acquired through the communications layer. System item values are usually generated through internal calculations, measurements, and tracking by the DAS Engine.

System items, like ordinary items, are defined by the following properties:

- **Group:** The client group/OPC group is an arbitrary collection of items, not correlated.
- **Hierarchical location:** The device attached to the item, indicated by link name/OPC path. The path contains the hierarchical node section of the fully qualified OPC item ID.
- **Device group:** A collection of items on the same physical location with the same protocol update rate. The device group is indicated by OPC access path/topic.

For DDE/SuiteLink clients, `$$SYS$$Status` always comes from the leaf level of a DAServer hierarchy branch, which is the destination PLC node. For OPC clients, `$$SYS$$Status` can be accessed at all hierarchy levels. `$$SYS$$Status` at the root level of the whole hierarchy tree is always good, as it represents the quality status of the local computer itself. For practical application, OPC clients should reference `$$SYS$$Status` at any hierarchy levels other than the root.

All system items follow the same naming convention:

- All system items start with `$$SYS$$`.
- The DAS Engine scans and parses the name for system items.
- Parsing of the name is case-insensitive.

All system items can be accessed through subscriptions to a device group. However, while some system items return data for that device group, others are server-wide.

Global System Item

The following system item refers to specific information regarding a global condition of the DAServer.

System Item Name	Type/Access Rights	Description	Values
<code>\$\$SYS\$\$Licensed</code>	Boolean/Read	Binary status indication of the existence of a valid license for the DAServer. If FALSE, this item causes the DAServer to stop updating existing tags, to refuse activation of new tags, and to reject write requests in addition to setting quality for all items to BAD. If TRUE, the DAServer functions as configured. All instances have the same value.	RANGE: 0, 1 0: No valid license exists. 1: Valid license exists.

Device-Group-Specific System Items

The following system items refer to specific information regarding device groups that are configured in the DAServer.

System Item Name (Type)	Type/Access Rights	Description	Values
\$SYS\$updateInterval	DWord/Read Write	Accesses the currently set update interval. It is the current update interval of the device group in milliseconds. A client can poke new values into this item. The value of zero indicates that non-system items on that topic are not updated. Data for these items are not acquired from the device.	RANGE: 1...2147483647 0: Topic inactive, no items are updated. Data acquisition is stopped. >0: Expected updated interval for the set of all items in the device group.
\$SYS\$maxInterval	DWord/Read	Not supported by this DAServer.	Always returns zero.

System Item Name (Type)	Type/Access Rights	Description	Values
\$SYS\$WriteComplete	Integer/Read Write	<p>Accesses the state of pending write activities on the corresponding device group. On device group creation (adding items to an OPC group), the value of this system item is initially 1, indicating all write activities are complete – no pokes are pending.</p> <p>If values are poked into any items of the device group, the value of this item changes to 0, indicating write activity is currently in progress.</p> <p>If the server has completed all write activities, the value of this item changes to 1 if all pokes were successful or to -1 if at least one poke has failed.</p> <p>If the value of this item is not zero, you can poke 1 or -1 to it. Poke a 1 to clear errors, or a -1 to test a client reaction on write errors.</p> <p>If the value of this item is zero, it cannot be poked.</p>	<p>RANGE: -1, 0, 1</p> <p>-1: Writes completed with errors.</p> <p>0: Writes are pending.</p> <p>1: Write complete. No writes are pending – initial state.</p>

System Item Name (Type)	Type/Access Rights	Description	Values
\$SYS\$ReadComplete	Integer/ ReadWrite	<p>Accesses the state of initial reads on all items in the corresponding device group. The value is 1 if all active items in a device group have been read at least one time.</p> <p>If at least one item in the device group is activated, this item changes to 0. It changes to 1 if all items have been read successfully, or to -1 if at least one item has a non-good quality.</p> <p>Poking a 0 to this item resets the internal read states of all items in this device group. This resets this item to 0. If all items are read again after this poke, this item changes back to 1 or -1.</p>	<p>RANGE: -1, 0, 1</p> <p>-1: All values were read but some have a non-good quality.</p> <p>0: Not all values were read.</p> <p>1: Read complete. All values were read.</p>
\$SYS\$ItemCount	DWord/Read	<p>Accesses the number of items in the corresponding device group. This item is read-only.</p>	<p>RANGE: 0...2147483647</p> <p>>=0: Number of items.</p>
\$SYS\$ActiveItemCount	DWord/Read	<p>Accesses the number of active items in the corresponding device group. This item is read-only.</p>	<p>RANGE: 0...2147483647</p> <p>>=0: Number of active items.</p>

System Item Name (Type)	Type/Access Rights	Description	Values
\$SYS\$errorCount	DWord/Read	Accesses the number of all active and inactive items that have non-good OPC quality errors in the corresponding topic. If the communications status of a device group is bad, all items have errors. This item is read-only.	RANGE: 0...2147483647 >=0: Number of all active and inactive items with errors.
\$SYS\$PollNow	Boolean/Read Write	Not supported by this DAServer.	

Device-Specific System Items

The following system items refer to specific information regarding the device(s) the DAServer is connected to.

System Item Name (Type)	Type/Access Rights	Description	Values
\$SYS\$Status	Boolean/Read	<p>Binary status indication of the connection state to the device (hierarchy level) the item is attached to. The device group (OPC access path/topic) does not affect the value.</p> <p>The status can be good even if individual items have errors.</p> <p>For DDE/SuiteLink clients, \$SYS\$Status always comes from the leaf level of a DAServer hierarchy branch, which is the destination PLC node. For OPC clients, \$SYS\$Status can be accessed at all hierarchy levels. \$SYS\$Status at the root level of the whole hierarchy tree is always good, as it represents the quality status of the local computer itself. For practical application, OPC clients should reference \$SYS\$Status at any hierarchy levels other than the root.</p>	<p>RANGE: 0, 1</p> <p>0: Error communicating with the device.</p> <p>1: DAServer connection to the device is intact.</p>

System Item Name (Type)	Type/Access Rights	Description	Values
\$SYS\$ErrorCode	Longint/Read	Detailed error code of the communications state to the device. The device group (OPC access path/topic) does not affect the value.	>= 0: Good status. 0 is the default state – connected. >0: Some device state like: connecting, initializing, and so on. <0: Error status. Value indicates the error.
\$SYS\$ErrorText	String/Read	Detailed error string of the communications state of the device. The device group (OPC access path/topic) does not affect the value.	Descriptive text for the communications state corresponding to the error code.

System Item Name (Type)	Type/Access Rights	Description	Values
\$SYS\$StoreSettings	Integer/Read Write	<p>Makes the temporary update interval changes via the \$SYS\$updateInterval item permanent. If the client pokes a value of 1 into this system item, the currently set update interval is written to the server's configuration file.</p> <p>The value of this system item clears to 0 after being set, if the configuration file write is successful. If the write fails, then the value is set to -1.</p> <p>If the update interval changes via the \$SYS\$updateInterval item and this item is not poked to 1, the DAServer uses the original update interval for that topic the next time it is started.</p> <p>Reading the item always provides 0. Read/Write values are persisted only if you set this system item. The values other than this persist only for the life of the DAServer.</p>	<p>RANGE: -1, 0, 1</p> <p>-1: Error occurred while saving the configuration file.</p> <p>0: Read value always if status is OK.</p> <p>1: Persist settings. Cleared immediately.</p>

Supported Data Types

The data type is specified as a suffix in the item syntax. The DAServer supports the following data types.

Data Type	Description
Boolean	Single bit
Short	Signed 16 bit value. Bit 0 is the low bit. Bit 14 is the high bit. Bit 15 is the sign bit.
Word	Unsigned 16 bit value. Bit 0 is the low bit. Bit 15 is the high bit.
Long	Signed 32 bit value. Bit 0 is the low bit. Bit 30 is the high bit. Bit 31 is the sign bit.
DWord	Unsigned 32 bit value. Bit 0 is the low bit. Bit 31 is the high bit.
Float	32 bit floating point value.
BCD	Two byte packed BCD. Value range is 0 - 9999. Behavior is undefined for values beyond this range.
LBCD	Four byte packed BCD. Value range is 0 - 99999999. Behavior is undefined for values beyond this range.
String	Null terminated ASCII string. Support includes HiLo and LoHi byte order selection and string lengths up to 512 characters.

Format and Syntax

Item references have four attributes:

- **Device Type** defines what the memory location can be used for. Device types include inputs, outputs, link relays, latch relays, and others. For device type limitations, see your PLC documentation. In this case, device type does not refer to the model of PLC.
- **Range** defines the valid addresses. Addresses are usually specified as one or more letters indicating the device type and a number. The number is specified as a hex or decimal value from 0 to an upper limit. Hexadecimal numbers must always start with a valid decimal digit. For example, the offset C3 is written as 0C3.
- **Data Type** defines which data type the client request can specify when accessing the memory location. Examples are Short and Word. For a complete list of valid data types, see Supported Data Types on page 58. The data type is often optional because most memory locations have a default data type.
- **Access** defines what the client can do. Some memory locations are read only or write only, others are read/write.

You can use optional item name suffixes to change the default server data format. The suffixes are listed in the **Supported Suffixes** columns of the Address Descriptions on page 64.

Note Item name suffixes are case insensitive.

Unsigned/Signed Format

The server can interpret data in 16-bit signed format (-32768 to 32767).

For example, channel DM100 in a C200H PLC contains 8000 hex. Unsigned quantities are read from this channel by one of two methods,

- Enter the item name.
- Append the letter **U** to the item name.

Therefore, item name **DM100** or **DM100U** appears in InTouch or Excel as 32768.

Signed quantities can be read from this same channel by appending the letter **S** to the item name. Therefore, item name **DM100S** appears in InTouch or Excel as -32768.

For tables showing allowable usage for each memory address, see Address Descriptions on page 64.

BCD Format

The OMRON PLC family supports BCD (Binary Coded Decimal) data representation and manipulation within their instruction sets.

To read or write data using BCD format, append the letter **B** to the item name. The **@BCD** suffix can also be used.

For example, the item name **DM100B** or **DM100@BCD** reads and writes a channel in BCD format.

Long Format (Signed/BCD)

Two consecutive 16-bit words in a PLC can be interpreted as a 32-bit long integer. It can be formatted as either signed (-2,147,483,648 to 2,147,483,648) or BCD (0 to 99,999,999).

To read or write an item in signed long format, append the letter **L** to the item name. You can also use the **@long** suffix.

To read or write an item in BCD long format, append the letter **M** to the item name. You can also use the **@LBCD** suffix.

For example, if DM100 contains 0234 hex and DM101 contains 1356 hex, **DM100L** or **DM100@long** returns 324,403,764 and **DM100M** or **DM100@LBCD** returns 13,560,234.

Floating Point Format (IEEE)

Two consecutive 16-bit words in a PLC can be interpreted as a single precision floating point number. It is formatted as either IEEE (-3.402823×10^{38} to $+3.402823 \times 10^{38}$).

To read or write an item in IEEE floating point format, append the letter **F** to the item name.

Note IEEE format is NOT supported in the C-Series PLC family.

ASCII Strings Format

Multiple consecutive 16-bit words (block size of 1 to 29) in a PLC can be interpreted as a string of ASCII characters. The ASCII string is stored/retrieved from the lowest-numbered address to the highest, and from the high-order byte to the low-order byte with each address.

To define a range of words, use a dash (-) between the two address locations. For example, **DM10-DM12** indicates locations from DM10 to DM12.

ASCII string characters can be specified to come from the low-order byte, high-order byte, or both bytes of the words.

- **Low-order Byte:** Only the low-order byte (LSB - least significant 8-bits) of each word is used for read/write.

To use this format, append the letter **E** to the item name.

- **High-order Byte:** Only the high-order byte (MSB - most significant 8-bits) of each word is used for read/write.

To use this format, append the letter **D** to the item name.

- **Both Bytes:** Both bytes of each word are used for read/write.

To use this format, append the letter **C** to the item name.

Note All bytes in the specified memory range are used.

If the string is shorter than the range of memory specified, it is padded with **\0**. If the string is longer than the range of memory specified, the string will be truncated.

For example, assume the following memory contents (numeric values shown in hex):

Item Reference	MSB	LSB	ASCII Equivalent
DM10	41	42	AB
DM11	43	44	CD
DM12	45	46	EF

Read:

- DM10 - DM12C returns ABCDEF
- DM10 - DM12D returns ACE
- DM10 - DM12E returns BDF

Write:

- DM10 - DM12C after written with "Test"

Item Reference	MSB	LSB	ASCII Equivalent
DM10	54	65	Te
DM11	73	74	st
DM12	0	0	“ “

- DM10 - DM12E after written with "ABCDE"

Item Reference	MSB	LSB	ASCII Equivalent
DM10	0	41	A
DM11	0	42	B
DM12	0	43	C

Alternate ASCII String Format

You can use the following ASCII String Format only with Data Memory (DM), Expansion Data Memory (EM), and Core IO Channel (CIO) device types.

When you use data memory for string data, each register contains two bytes (two characters) of ASCII data. The order of the ASCII data within a given register can be selected when the string is defined.

The length of the string can be from 2 to 58 characters. The length is entered in place of a bit number and must be an even number.

The range of registers spanned by the string cannot exceed the range of the device type. The byte order is specified by appending either an **H** or an **L** to the address.

For example:

- You address a string starting at DM100 with a length of 20 bytes and HiLo byte as **DM100.20H**.
- You address a string starting at DM110 with a length of 24 bytes and LoHi byte as **DM110.24L**.

Bit Access

Individual bits of register device types can be accessed as Booleans. To reference a particular bit, append a bit number .bb (.bit) or :bb (:bit) to the address of the register.

The bit number is always in decimal notation.

- 0 - 15 for Short, Word, BCD
- 0 - 31 for Long, DWord, and LBCD

For example:

- **D1.0** or **D1:0** is the least significant bit of D1.
- **D1.15** or **D1:15** is the most significant bit of D1.

Array Access

You can use arrays with all data types except Boolean. The number of array elements cannot exceed the request size that has been assigned to the device.

For example **DMxxxx [elements]**.

For DDE/SuiteLink client, array data is returned as a string in HexASCII format.

Using 32-bit Values

Be careful when modifying 32-bit values (DWord, Long, LBCD, and Float). Each address for which these data types are allowed can start at any word offset. For example, writes to DWords DM0 (referencing words 0 and 1) and DM1 (referencing words 1 and 2) both change word DM1.

It is recommended that you use these data types so that overlapping does not occur. For example, when using DWords, you might want to use DM0, DM2, DM4, and so on, to prevent overlapping words.

Address Descriptions

The address descriptions consist of the device type, its item name and the allowable range of values, the default data type, allowable suffix values, and allowable access methods.

C200 Address Descriptions

Model C200 supports the following types of devices.

Note Expansion Data Memory in the C200 Series PLC can be accessed using syntax EA, EB, EC...where EA refers to EM0 memory area of the PLC, and so on. The range of the Expansion Data Memory depends upon the CPU type.

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Auxiliary Relay	ARn	n=00 to 27	Word	@word, @short, @BCD, u,s,b,d,e,c	Read/ Write
		n=00 to 26		@long, @dword, @LBCD, @float l,f,m	
		n=xx:pp or n=xx.pp, xx=00 to 27, pp=00 to 15	Boolean		

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Data Memory	DMn	n=0000 to 6655	Word	@word, @short, @BCD, u,s,b,d,e,c	Read/ Write
		n=0000 to 6654		@long, @dword, @LBCD, @float l,f,m	
		n=xxxx.pp or n=xxxx:pp, xxxx=0000 to 6655, pp=00 to 15	Boolean		
		n=xxxx.yyyH xxxx=0000 to 6655 yyy=002 to 512 (String length must be an even number).	String (with HiLo byte order)	Read/ Write	
		n=xxxx.yyyL xxxx=0000 to 6655 yyy=002 to 512 (String length must be an even number).	String (with LoHi byte order)	Read/ Write	

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Expansion Data Memory EM (current bank)	EMn	n=0000 to 6143	Word	@word, @short, @BCD, u,s,b,d,e,c	Read/ Write
		n=0000 to 6142		@long, @dword, @LBCD, @float, l,f,m	
		n=xxxx.pp or n=xxxx:pp, xxxx=0000 to 6143, pp=00 to 15	Boolean		
		n=xxxx.yyyH, xxxx=0000 to 6143, yyy=002 to 512 (String length must be an even number).	String (with HiLo byte order)	Read/ Write	
		n=xxxx.yyyL, xxxx=0000 to 6143, yyy=002 to 512 (String length must be an even number).	String (with LoHi byte order)	Read/ Write	

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Expansion Data Memory	En	n=zxxxx, z=A to H, xxxx=0000 to 6143	Word	@word, @short, @BCD, u,s,b,d,e,c	Read/ Write
		n=zxxxx, z=A to H, xxxx=0000 to 6142		@dword, @long, @LBCD, @float, l,f,m	
		n=zxxxx.pp or n=zxxxx:pp, z=A to H, xxxx=0000 to 6143 pp=00 to 15	Boolean		
		n=zxxxx.yyyH, z=A to H, xxxx=0000 to 6143, yyy=002 to 512 (String length must be an even number)	String (with HiLo byte order)		Read/ Write
		n=zxxxx.yyyL, z=A to H, xxxx=0000 to 6143, yyy=002 to 512 (String length must be an even number)	String (with LoHi byte order)		Read/ Write

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Holding Relay	HRn	n=00 to 99	Word	@word, @short, @BCD, u,s,b,d,e,c	Read/ Write
		n=00 to 98		@long, @dword, @LBCD, @float l,f,m	
		n=xx:pp or n=xx.pp, xx=00 to 99, pp=00 to 15	Boolean		
Internal Relay	IRn	n=000 to 511	Word	@word, @short, @BCD, u,s,b	Read/ Write
		n=000 to 510		@long, @dword, @LBCD, @float, l,f,m	
		n=xxx:pp or n=xxx.pp, xxx=000 to 511, pp=00 to 15	Boolean		
Alias for Internal Relay	CHn	n=000 to 511	Word	@word, @short, @BCD, u,s,b,	Read/ Write
		n=xxx:pp or n=xxx.pp, xxx= 000 to 511, pp=00 to 15	Boolean		

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Link Relays	LRn	n=00 to 63	Word	@word, @short, @BCD, u,s,b,d,e,c	Read/ Write
		n=00 to 62		@long, @dword, @LBCD, @float, l,f,m	
		n=xx:pp or n=xx.pp, xx= 00 to 63, pp=00 to 15	Boolean		
Timer/Counter	PVn	n=000 to 511	Word	@word, @short, @BCD, u,s,b,d,e,c	Read/ Write
Timer/Counter Status	TCn	n=000 to 511	Boolean		Read Only

CV500 Address Descriptions

Model CV500 supports the following types of devices.

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Action Flag	ACn	n=0000 to 1023	Boolean		Read Only
Auxiliary Relay	An	n=000 to 255	Word	@word, @short, @BCD, u,s,b,d,e,c	Read/Write
		n=000 to 254		@long, @dword, @LBCD, @float, f,l,m	
		n=256 to 511	Word	@word, @short, @BCD, u,s,b,d,e,c	Read Only
		n=256 to 510		@long, @dword, @LBCD, @float, f,l,m	
		n= xxx.pp or n=xxx:pp, xxx= 000 to 255, pp=00 to 15	Boolean		Read/Write
		n= xxx.pp or n=xxx:pp, xxx= 256 to 511, pp=00 to 15	Boolean		Read Only

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Core I/O Channel	CION	n=0000 to 2555	Word	@word, @short, @BCD, u,s,b,d,e,c	Read/ Write
		n=0000 to 2554		@long, @dword, @LBCD, @float, f,l,m	
		n= xxxx.pp or n=xxxx:pp, xxxx= 0000 to 2555, pp=00 to15	Boolean		
		n=xxxx.yyyH, xxxx=0000 to 2555, yyy=002 to 512 (String length must be an even number.)	String (with HiLo byte order.)		
		n=xxxx.yyyL, xxxx=0000 to 2555, yyy=002 to 512 (String length must be an even number.)	String (with LoHi byte order.)		
Counter	PVCn	n=000 to 511	Word	@word, @short, @BCD, u,s,b,d,e,c	Read/ Write
Counter Status	Cn	n=000 to 511	Boolean		Read Only

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
CPU Bus Link	Gn	n=000 to 255	Word	@word, @short, @BCD, u,s,b,d,e,c	Read/ Write
		n=000 to 254		@long, @dword, @LBCD, @float, f,l,m	
		n= xxx.pp or n=xxx:pp, xxx= 000 to 255, pp=00 to15	Boolean		
Data Memory	Dn	n=0000 to 8191	Word	@word, @short, @BCD, u,s,b,d,e,c	Read/ Write
		n=0000 to 8190		@long, @dword, @LBCD, @float, f,l,m	
		n= xxxx.pp or n=xxxx:pp, xxxx= 0000 to 8191, pp=00 to15	Boolean		
		n=xxxx.yyyH xxxx=0000 to 8191, yyy=002 to 512 (String length must be an even number.)	String (with HiLo byte order)	Read/ Write	
		n=xxxx.yyyL xxxx=0000 to 8191, yyy=002 to 512 (String length must be an even number.)	String (with LoHi byte order)	Read/ Write	

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Data Register	DRn	n=0 to 2	Word (arrays not supported)		Read/ Write
Index Register	IRn	n=0 to 2	Word (arrays not supported)	b	Read Only
Step Timer	STCn	n=000 to 511	Word (arrays not supported)		Read/ Write
Step Timer Status	STn	n=000 to 511	Boolean		Read Only
Timer	PVTn	n=000 to 511	Word	@word, @short, @BCD, u,s,b,d,e,c	Read/ Write
Timer Status	Tn	n=000 to 511	Boolean		Read Only
Transition Area	TNn	n=000 to 511	Boolean		Read Only

CV1000 and CV2000 Address Descriptions

Models CV1000 and CV2000 support the following types of devices.

Note Expansion Data Memory in CV1000/CV2000 Series PLCs can be accessed using syntax EA, EB, EC...where EA refers to the E0 memory area of the PLC, and so on. The range of the Expansion Data Memory depends on the CPU type.

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Action Flag	ACn	n=0000 to 2047	Boolean		Read Only
Auxiliary Relay	An	n=000 to 255	Word	@word, @short, @BCD, u,s,b,d,e,c	Read/Write
		n=000 to 254		@long, @dword, @LBCD, @float, f,l,m	
		n=256 to 511	Word	@word, @short, @BCD, u,s,b,d,e,c	Read Only
		n=256 to 510		@long, @dword, @LBCD, @float, f,l,m	
		n= xxx.pp or n=xxx:pp, xxx= 000 to 255, pp=00 to 15	Boolean		Read/Write
n= xxx.pp or n=xxx:pp, xxx= 256 to 511, pp=00 to 15	Boolean		Read Only		

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Core I/O Channel	CION	n=0000 to 2555	Word	@word, @short, @BCD, u,s,b,d,e,c	Read/ Write
		n=0000 to 2554		@long, @dword, @LBCD, @float, f,l,m	
		n= xxxx.pp or n=xxxx:pp, xxxx= 0000 to 2555, pp=00 to 15	Boolean		
		n=xxxx.yyyH, xxxx=0000 to 2555, yyy=002 to 512 (String length must be an even number.)	String (with HiLo byte order.)		
		n=xxxx.yyyL, xxxx=0000 to 2555, yyy=002 to 512 (String length must be an even number.)	String (with LoHi byte order.)		
Counter	PVCn	n=000 to 1023	Word	@word, @short, @BCD, u,s,b,d,e,c	Read/ Write
Counter Status	Cn	n=000 to 1023	Boolean		Read Only

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
CPU Bus Link	Gn	n=000 to 255	Word	@word, @short, @BCD, u,s,b,d,e,c	Read/ Write
		n=000 to 254		@long, @dword, @LBCD, @float, f,l,m	
		n= xxx.pp or n=xxx:pp, xxx= 000 to 255, pp=00 to15	Boolean		
Data Memory	Dn	n=00000 to 24575	Word	@word, @short, @BCD, u,s,b,d,e,c	Read/ Write
		n=00000 to 24574		@long, @dword, @LBCD, @float, f,l,m	
		n= xxxxx.pp or n=xxxxx:pp, xxxxx= 00000 to 24575, pp=00 to15	Boolean		
		n=xxxxx.yyyH xxxxx=00000 to 24575, yyy=002 to 512 (String length must be an even number.)	String (with HiLo byte order)		Read/ Write
		n=xxxxx.yyyL xxxxx=00000 to 24575, yyy=002 to 512 (String length must be an even number.)	String (with LoHi byte order)		Read/ Write

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Data Register	DRn	n=0 to 2	Word (arrays not supported)		Read/ Write
Expansion Data Memory (current bank)	En	n=00000 to 32765	Word	@word, @short, @BCD, u,s,b,d,e,c	Read/ Write
		n=00000 to 32764		@long, @dword, @LBCD, @float, f,l,m	
		n= xxxxx.pp or n=xxxxx:pp, xxxxx= 00000 to 32765, pp=00 to15	Boolean		
		n=xxxxx.yyyH xxxxx=00000 to 32765, yyy=002 to 512 (String length must be an even number.)	String (with HiLo byte order)	Read/ Write	
n=xxxxx.yyyL xxxxx=00000 to 32765, yyy=002 to 512 (String length must be an even number.)	String (with LoHi byte order)	Read/ Write			

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access	
Expansion Data Memory	En	n=zxxxxx, z=A to H, xxxxx=00000 to 32765	Word	@word, @short, @BCD, u,s,b,d,e,c	Read/ Write	
		n=zxxxxx, z=A to H, xxxxx=00000 to 32764		@long, @dword, @LBCD, @float, f,l,m		
		n=zxxxxx.pp or n=zxxxxx:pp, z = A to H, xxxxx=00000 to 32765, pp=00 to 15	Boolean			
		n=zxxxxx.yyyH, z=A to H, xxxxx=00000 to 32765, yyy=002 to 512 (String length must be an even number.)	String (with HiLo byte order)		Read/ Write	
		n=zxxxxx.yyyL, z=A to H, xxxxx=00000 to 32765, yyy=002 to 512 (String length must be an even number.)	String (with LoHi byte order)		Read/ Write	
Index Register	IRn	n=0 to 2	Word (arrays not supported)	b	Read Only	
Step Timer	STCn	n=000 to 1023	Word (arrays not supported)		Read/ Write	
Step Timer Status	STn	n=000 to 1023	Boolean		Read Only	

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Temporary Relay (CV 2000 ONLY)	TR		Word	@short, @word	Read/ Write
	TRn	n=0 to 7	Boolean		
Timer	PVTn	n=000 to 1023	Word	@word, @short, @BCD, u,s,b,d,e,c	Read/ Write
Timer Status	Tn	n=000 to 1023	Boolean		Read Only
Transition Area	TNn	n=000 to 1023	Boolean		Read Only

CVM1-CPU01 Address Descriptions

Model CVM1-CPU01 supports the following types of devices.

Note Expansion Data Memory in the CVM Series PLC can be accessed using syntax EA, EB, EC... where EA refers to E0 memory area of the PLC, and so on. The range of the Expansion Data Memory depends upon the CPU type.

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Auxiliary Relay	An	n=000 to 255	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
		n=000 to 254		@long, @dword, @LBCD, @float, f,l,m	
		n=256 to 511	Word	@short, @word, @BCD, u,s,b,d,e,c	Read Only
		n=256 to 510		@long, @dword, @LBCD, @float, f,l,m	
		n=xxx.pp or n=xxx:pp, xxx=000 to 255, pp=00 to 15	Boolean		Read/Write
		n=xxx.pp or n=xxx:pp, xxx= 256 to 511, pp=00 to 15	Boolean		Read Only

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
CIO	CION	n=0000 to 2555	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
		n=0000 to 2554		@long, @dword, @LBCD, @float, f,l,m	
		n=xxxx.pp or n=xxxx:pp, xxxx= 0000 to 2555, pp=00 to 15	Boolean		
		n=xxxx.yyyH, xxxx=0000 to 2555, yyy=002 to 512 (String length must be an even number.)	String (with HiLo byte order)		
		n=xxxx.yyyL, xxxx=0000 to 2555, yyy=002 to 512 (String length must be an even number.)	String (with LoHi byte order)		
Counter	PVCn	n=000 to 511	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
Counter Status	Cn	n=000 to 511	Boolean		Read Only

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
CPU Bus Link	Gn	n=000 to 255	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
		n=000 to 254		@long, @dword, @LBCD, @float, f,l,m	
		n=xxx.pp or n=xxx:pp, xxx=000 to 255, pp=00 to 15	Boolean		

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Data Memory	Dn	n=0000 to 8191	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
		n=0000 to 8190		@long, @dword, @LBCD, @float, f,l,m	
		n=xxxx.pp or n=xxxx:pp, xxxx= 0000 to 8191, pp=00 to 15	Boolean		
		n=xxxx.yyyH, xxxx = 0000 to 8191, yyy = 002 to 512 (String length must be an even number.)	String (with HiLo byte order)		
		n=xxxx.yyyL, xxxx = 0000 to 8191, yyy = 002 to 512 (String length must be an even number.)	String (with LoHi byte order)		
Data Register	DRn	n=0 to 2	Word (arrays not supported)		Read/Write
Index Register	IRn	n=0 to 2	Word (arrays not supported)		Read Only
Timer	PVTn	n=000 to 511	Word	@short, @word, @BCD u,s,b,d,e,c	Read/Write

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Timer Status	Tn	n=000 to 511	Boolean		Read Only

CVM1-CPU11 Address Descriptions

Model CVM1-CPU11 supports the following types of devices.

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Auxiliary Relay	An	n=000 to 255	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
		n=000 to 254		@long, @dword, @LBCD, @float, f,l,m	
		n=256 to 511	Word	@short, @word, @BCD, u,s,b,d,e,c	Read Only
		n=256 to 510		@long, @dword, @LBCD, @float, f,l,m	
		n=xxx.pp or n=xxx:pp, xxx= 000 to 255, pp=00 to 15	Boolean		Read/Write
		n=xxx.pp, xxx=256 to 511, pp=00 to 15	Boolean		Read Only

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
CIO	CION	n=0000 to 2555	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
		n=0000 to 2554		@long, @dword, @LBCD, @float, f,l,m	
		n=xxxx.pp or n=xxxx:pp, xxxx= 0000 to 2555, pp=00 to 15	Boolean		
		n=xxxx.yyyH xxxx=0000 to 2555, yyy=002 to 512 (String length must be an even number.)	String (with HiLo byte order)		
		n=xxxx.yyyL xxxx=0000 to 2555, yyy=002 to 512 (String length must be an even number.)	String (with LoHi byte order)		
Counter	PVCn	n=000 to 1023	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
Counter Status	Cn	n=000 to 1023	Boolean		Read Only

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
CPU Bus Link	Gn	n=000 to 255	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
		n=000 to 254		@long, @dword, @LBCD, @float, f,l,m	
		n=xxx.pp or n=xxx:pp, xxx= 000 to 255, pp=00 to 15	Boolean		

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Data Memory	Dn	n=00000 to 24575	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
		n=00000 to 24574		@long, @dword, @LBCD, @float, f,l,m	
		n=xxxxx.pp or n=xxxxx:pp, xxxxx= 00000 to 24575, pp=00 to 15	Boolean		
		n=xxxx.yyyH, xxxx = 0000 to 24575, yyy = 002 to 512 (String length must be an even number.)	String (with HiLo byte order)		
		n=xxxx.yyyL, xxxx = 0000 to 24575, yyy = 002 to 512 (String length must be an even number.)	String (with LoHi byte order)		
Data Register	DRn	n=0 to 2	Word (arrays not supported)		Read/Write
Index Register	IRn	n=0 to 2	Word		Read Only
Timer	PVTn	n=000 to 1023	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
Timer Status	Tn	n=000 to 1023	Boolean		Read Only

CVM1-CPU21 Address Descriptions

Model CVM1-CPU21 supports the following types of devices.

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Auxiliary Relay	An	n=000 to 255	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
		n=000 to 254		@long, @dword, @LBCD, @float, f,l,m	
		n=256 to 511	Word	@short, @word, @BCD, u,s,b,d,e,c	Read Only
		n=256 to 510		@long, @dword, @LBCD, @float, f,l,m	
		n=xxx.pp or n=xxx:pp, xxx= 000 to 255, pp=00 to 15	Boolean		Read/Write
		n=xxx.pp or n=xxx:pp, xxx= 256 to 511, pp=00 to 15			

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
CIO	CION	n=0000 to 2555	Word	@short, @word, @BCD, u,s, b,d,e,c	Read/Write
		n=0000 to 2554		@long, @dword, @LBCD, @float, f,l,m	
		n=xxxx.pp or n=xxxx:pp, xxxx= 0000 to 2555, pp=00 to 15	Boolean		
		n=xxxx.yyyH, xxxx=0000 to 2555, yyy=002 to 512 (String length must be an even number.)	String (with HiLo byte order)		
		n=xxxx.yyyL,x xxx=0000 to 2555, yyy=002 to 512 (String length must be an even number.)	String (with LoHi byte order)		
Counter	PVCn	n=0000 to 1023	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
Counter Status	Cn	n=000 to 1023	Boolean		Read Only

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
CPU Bus Link	Gn	n=000 to 255	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
		n=000 to 254		@long, @dword, @LBCD, @float, f,l,m	
		n=xxx.pp or n=xxx:pp, xxx= 000 to 255, pp=00 to 15	Boolean		

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Data Memory	Dn	n=00000 to 24575	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
		n=00000 to 24574		@long, @dword, @LBCD, @float, f,l,m	
		n=xxxxx.pp or n=xxxxx:pp, xxxxx= 00000 to 24575, pp=00 to 15	Boolean		
		n=xxxx.yyyH, xxxx = 0000 to 24575, yyy = 002 to 512 (String length must be an even number.)	String (with HiLo byte order)		
		n=xxxx.yyyL, xxxx = 0000 to 24575, yyy = 002 to 512 (String length must be an even number.)	String (with LoHi byte order)		
Data Register	DRn	n=0 to 2	Word (arrays not supported)		Read/Write

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Expansion Data Memory (Current Bank)	En	n=00000 to 32765	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
		n=00000 to 32764		@long, @dword, @LBCD, @float, f,l,m	
		n=xxxxx.pp or n=xxxxx:pp, xxxxx=00000 to 32765, pp=00 to 15	Boolean		
		n=xxxxx.yyyH , xxxxx=00000 to 32765, yyy=002 to 512 (String length must be an even number.)	String (with HiLo byte order)		
		n=xxxxx.yyyL, xxxxx=00000 to 32765, yyy=002 to 512 (String length must be an even number.)	String (with LoHi byte order)		

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Expansion Data Memory	En	n=zxxxxx, z =A to H, xxxxx=00000 to 32765	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
		n=zxxxxx, z =A to H, xxxxx=00000 to 32764		@long, @dword, @LBCD, @float, f,l,m	
		n=zxxxxx.pp or n=zxxxxx:pp, z =A to H, xxxxx=00000 to 32765, pp=00 to 15	Boolean		
		n=zxxxxx.yyy H, z =A to H, xxxxx=00000 to 32765, yyy=002 to 512 (String length must be an even number.)	String (with HiLo byte order)		
		n=zxxxxx.yyy L, z =A to H, xxxxx=00000 to 32765, yyy=002 to 512 (String length must be an even number.)	String (with LoHi byte order)		
Index Register	IRn	n=0 to 2	Word (arrays not supported)		Read Only

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Timer	PVTn	n=000 to 1023	Word	@short, @word, @BCD, u,s,b,c,e,d	Read/Write
Timer Status	Tn	n=0000 to 1023	Boolean		Read Only

CS1 Address Descriptions

Model CS1 supports the following types of devices.

Note Expansion Data Memory in the CS1 Series PLC can be accessed using syntax EA, EB, EC... where EA refers to E0 memory area of the PLC, and so on. The range of the Expansion Data Memory depends upon the CPU type.

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Auxiliary Relay	An	n=000 to 447	Word	@short, @word, @BCD, u,s,b,d,e,c	Read Only
		n=000 to 446		@long, @dword, @LBCD, @float, f,l,m	
		n=448 to 959	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
		n=448 to 958		@long, @dword, @LBCD, @float, f,l,m	
		n=xxx.pp or n=xxx:pp, xxxx= 000 to 447, pp=00 to 15	Boolean		Read Only
		n=xxx.pp or n=xxx:pp, xxx= 448 to 959, pp=00 to 15	Boolean		Read/Write

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
CIO	CIO _n	n=0000 to 6143	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
		n=0000 to 6142		@long, @dword, @LBCD, @float, f,l,m	
		n=xxxx.pp or n=xxxx:pp, xxxx= 0000 to 6143, pp=00 to 15	Boolean		
		n=xxxx.yyyH, xxxx=0000 to 6143, yyy=002 to 512 (String length must be an even number.)	String (with HiLo byte order)		
		n=xxxx.yyyL, xxxx=0000 to 6143, yyy=002 to 512 (String length must be an even number.)	String (with LoHi byte order)		
Counter	PVC _n	n=0000 to 4095	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
Counter Status	C _n	n=0000 to 4095	Boolean		Read Only

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Data Memory	Dn	n=00000 to 32767	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
		n=00000 to 32766		@long, @dword, @LBCD, @float, f,l,m	
		n=xxxxx.pp or n=xxxxx:pp, xxxxx=00000 to 32767, pp=00 to 15	Boolean		
		n=xxxxx.yyyH xxxxx = 00000 to 32767, yyy = 002 to 512 (String length must be an even number.)	String (with HiLo byte order)		
		n=xxxxx.yyyL xxxxx = 00000 to 32767, yyy = 002 to 512 (String length must be an even number.)	String (with LoHi byte order)		
Data Register	DRn	n=00 to 15	Word (arrays not supported)	@short, @word, @BCD, u,s,b	Read/Write*
		n=00 to 14		@long, @dword, @LBCD, @float, f,l,m	

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Expansion Data Memory (current bank)	En	n=00000 to 32767	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
		n=00000 to 32766		@long, @dword, @LBCD, @float, f,l,m	
		n=xxxxx.pp or n=xxxxx:pp, xxxxx=00000 to 32767, pp=00 to 15	Boolean		
		n=xxxxx.yyyH, xxxxx=00000 to 32767, yyy=002 to 512 (String length must be an even number.)	String (with HiLo byte orde)		
		n=xxxxx.yyyL, xxxxx=00000 to 32767, yyy=002 to 512 (String length must be an even number.)	String (with LoHi byte order)		

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Expansion Data Memory	En	n=zxxxxx , z =A to M, xxxxx=00000 to 32767	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
		n=zxxxxx, z =A to M, xxxxx=00000 to 32766		@long, @dword, @LBCD, @float, f,l,m	
		n=zxxxxx.pp or n=zxxxxx:pp, z =A to M, xxxxx=00000 to 32767, pp=00 to 15	Boolean		
		n=zxxxxx.yyyH, z =A to M, xxxxx=00000 to 32767, yyy=002 to 512 (String length must be an even number.)	String (with HiLo byte order)		
		n=zxxxxx.yyyL, z =A to M, xxxxx=00000 to 32767, yyy=002 to 512 (String length must be an even number.)	String (with LoHi byte order)		

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Holding Relay	Hn	n=0000 to 1535	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
		n=0000 to 1534		@long, @dword, @LBCD, @float, f,l,m	
		n=xxxx.pp or n=xxxx:pp, xxxx= 0000 to 1535, pp=00 to 15	Boolean		
Index Register	IRn	n=00 to 15	Long (arrays not supported)	m	Read/Write*
Task Flag	TKn	n=00 to 31	Boolean		Read Only
Timer	PVTn	n=0000 to 4095	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
Timer Status	Tn	n=0000 to 4095	Boolean		Read Only
Working Relay	Wn	n=000 to 511	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
		n=000 to 510		@long, @dword, @LBCD, @float, f,l,m	
		n=xxx:pp or n=xxx:pp, xxx=000 to 511 pp=00 to 15	Boolean		

* IR and DR registers can only be written to when the device is in programming mode. If the device is in Run Mode and a write is attempted to a DR or IR register, the write appears to succeed in DASServer diagnostics. However the value is not changed in the device and no message is logged in the Logger.

CJ1 Address Descriptions

Model CJ1 supports the following types of devices.

Note Expansion Data Memory in the CJ1 Series PLC can be accessed using syntax EA, EB, EC... where EA refers to E0 memory area of the PLC, and so on. The range of the Expansion Data Memory depends upon the CPU type.

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Auxiliary Relay	An	n=000 to 447	Word	@short, @word, @BCD, u,s,b,d,e,c	Read Only
		n=000 to 446		@long, @dword, @LBCD, @float, f,l,m	
		n=448 to 959	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
		n=448 to 958		@long, @dword, @LBCD, @float, f,l,m	
		n=xxx.pp or n=xxx:pp, xxx= 000 to 447, pp=00 to 15	Boolean		Read Only
		n=xxx.pp or n=xxx:pp, xxx= 448 to 959, pp=00 to 15	Boolean		Read/Write

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
CIO	CION	n=0000 to 6143	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
		n=0000 to 6142		@long, @dword, @LBCD, @float, f,l,m	
		n=xxxx.pp or n=xxxx:pp, xxxx= 0000 to 6143, pp=00 to 15	Boolean		
		n=xxxx.yyyH, xxxx=0000 to 6143, yyy=002 to 512 (String length must be an even number.)	String (with HiLo byte order)		
		n=xxxx.yyyL, xxxx=0000 to 6143, yyy=002 to 512 (String length must be an even number.)	String (with LoHi byte order)		
Counter	PVCn	n=0000 to 4095	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
Counter Status	Cn	n=0000 to 4095	Boolean		Read Only

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Data Memory	Dn	n=00000 to 32767	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
		n=00000 to 32766		@long, @dword, @LBCD, @float, f,l,m	
		n=xxxxx.pp or n=xxxxx:pp, xxxxx=00000 to 32767, pp=00 to 15	Boolean		
		n=xxxxx.yyyH xxxxx = 00000 to 32767, yyy = 002 to 512 (String length must be an even number.)	String (with HiLo byte order)		
		n=xxxxx.yyyL xxxxx = 00000 to 32767, yyy = 002 to 512 (String length must be an even number.)	String (with LoHi byte order)		
Data Register	DRn	n=00 to 15	Word	@short, @word, @BCD, u,s,b	Read/Write*
		n=00 to 14		@long, @dword, @LBCD, @float, f,l,m	

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Expansion Data Memory (current bank)	En	n=00000 to 32767	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
		n=00000 to 32766		@long, @dword, @LBCD, @float, f,l,m	
		n=xxxxx.pp or n=xxxxx:pp, xxxxx=00000 to 32767, pp=00 to 15	Boolean		
		n=xxxxx.yyyH, xxxxx=00000 to 32767, yyy=002 to 512 (String length must be an even number.)	String (with HiLo byte order)		
		n=xxxxx.yyyL, xxxxx=00000 to 32767, yyy=002 to 512 (String length must be an even number.)	String (with LoHi byte order)		

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Expansion Data Memory	En	n=zxxxxx, z =A to M, xxxxx=00000 to 32767	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
		n=zxxxxx, z =A to M, xxxxx=00000 to 32766		@long, @dword, @LBCD, @float, f,l,m	
		n=zxxxxx.pp or n=zxxxxx:pp, z =A to M, xxxxx=00000 to 32767, pp=00 to 15	Boolean		
		n=zxxxxx.yyyH, z =A to M, xxxxx=00000 to 32767, yyy=002 to 512 (String length must be an even number.)	String (with HiLo byte order)		
		n=zxxxxx.yyyL, z =A to M, xxxxx=00000 to 32767, yyy=002 to 512 (String length must be an even number.)	String (with LoHi byte order)		
Holding Relay	Hn	n=0000 to 1535	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
		n=0000 to 1534		@long, @dword, @LBCD, @float, f,l,m	
		n=xxxx.pp or n=xxxx:pp, xxxx= 0000 to 1535, pp=00 to 15	Boolean		

Device Type	Item Name	Range	Data Type	Supported Suffixes	Access
Index Register	IRn	n=00 to 15	Long	m	Read/Write*
Task Flag	TKn	n=00 to 31	Boolean		Read Only
Timer	PVTn	n=0000 to 4095	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
Timer Status	Tn	n=0000 to 4095	Boolean		Read Only
Working Relay	Wn	n=000 to 511	Word	@short, @word, @BCD, u,s,b,d,e,c	Read/Write
		n=000 to 510		@long, @dword, @LBCD, @float, f,l,m	
		n=xxx:pp or n=xxx:pp, xxx=000 to 511 pp=00 to 15	Boolean		

* IR and DR registers can only be written to when the device is in programming mode. If the device is in Run Mode and a write is attempted to a DR or IR register, the write appears to succeed in DAServer diagnostics. However the value is not changed in the device and no message is logged in the Logger.

Chapter 9

Troubleshooting

You can troubleshoot problems with the DAServer using the:

- Windows Task Manager
- Windows Performance and Alerts (PerfMon) application also called Performance Monitor
- DAServer Manager
- ArcestrA Log Flag Editor
- ArcestrA Log Viewer

Your client application may let you view error messages, monitor the status of requests, and allow you to request data on the status of the DAServer and connected devices. For more information, see your client application documentation.

Troubleshooting with Windows Tools

Windows has two tools that may be useful in troubleshooting performance problems.

You can find quick verification that the DAServer process is running by looking at the Windows Task Manager. It also provides information on the user, CPU, and memory usage of the processes.

If you need more information, or need to gather data while not logged in, you can use the Performance and Alerts application. For more information, see the Microsoft Management Console (MMC) help files on the Performance application. The Performance application is one of the administrative tools found in the Windows Control Panel.

Troubleshooting with the DAServer Manager

The DAServer Manager has information that may be useful in troubleshooting problems. When the DAServer is active, a diagnostic node is present below the configuration node in the console tree of the System Management Console.

Each diagnostic leaf contains information about DAServer activity. For more information, see the *DAServer Manager User Guide* or Help files.

Finding Version Information

If you contact Technical Support, you may need to supply version information.

To determine the DAServer Manager version

- ◆ In the DAServer Manager, right-click **DAServer Manager**, and then click **About DAServer Manager**. An **About** box appears showing the version and build date of the DAServer Manager.

To determine version information for DAServer components

- ◆ In the DAServer Manager, select the DAServer name in the console tree. The version information for each DAServer component is shown in the details pane.

Using the Wonderware Log Viewer

Error messages are created by the DAServer and logged by the Logger. You can view these messages with the Log Viewer. The Log Viewer help files explain how to view messages and how to filter which messages are shown.

Log Flags are categories of messages. The *Log Flag Editor User Guide* contains an explanation of the categories. Using the Log Flag Editor, you can specify which log flags the DAServer creates.

Note Generating large numbers of diagnostic messages can impact DAServer performance. You should not run in production with any more flags than those set when the DAServer is installed. To troubleshoot you can turn on more flags, but there is a performance impact. For more information, see the *Log Flag Editor User Guide*.

To open the Log Flag Editor

- 1 In the System Management Console, expand **Log Viewer** and then expand the log viewer group.
- 2 Select **Local**.
- 3 On the **Action** menu, click **Log Flags**.

In general, look at error and warning messages to determine if a problem exists. To determine whether the DASServer is communicating with a device, you can enable the DASSend and DASReceive log flags. From these you can determine whether or not the device is responding.

Basic Log Flags

The basic log flags for all ArcestrA components are:

- **Error:** A fatal error, the program cannot continue. By default set on by logger.
- **Warning:** The error is recoverable. A client called with a bad parameter, or the result of some operation was incorrect, but the program can continue. By default set on by logger.
- **Start-Stop:** Each main component logs a message to this category as it starts and stops.
- **Info:** General diagnostic messages.
- **Ctor-Dtor:** C++ classes of interest log messages to this category as they are constructed and destructed.
- **Entry-Exit:** Functions of interest log messages to this category as they are called and return.
- **Thread Start-Stop:** All threads should log messages to this category as they start and stop.

DAServer Log Flags

Messages created for these log flags are for DAServer common components and contain information about internal DAServer activities.

- **DACmnProtFail:** Some failure occurred in the common components while sending a message, updating an item, or otherwise moving data. Typically, this represents some unexpected behavior in the server-specific DLL.
- **DACmnProtWarn:** Some problem occurred that interfered with sending messages, updating items, or otherwise moving data. Common examples are slow poll, value limiting during type conversion, and transaction timeout messages.
- **DACmnTrace:** Normal processing of client program requests and data movement to and from the server-specific DLL are traced on this log flag. Use this in conjunction with DACmnVerbose to get the most information.
- **DACmnVerbose:** Many log flags used by the DAS common components are modified occasionally by DACmnVerbose. When DACmnVerbose is set, the logging of messages on other log flags includes more information.
- **DACmnSend:** Operations within the DAS Engine DLL that revolve around sending messages to the server-specific DLL.
- **DACmnReceive:** Events surrounding messages that are returned to the DAS Engine by the server-specific DLL, including the blocking and unblocking of hierarchies.

DAServer-Device Interface Log Flags

Messages created for the following log flags are specific to an individual DAServer and contain information about communications between the DAServer and device.

- **DASProtFail:** An error in the protocol occurred, for example, device disconnected. The program can continue, and, in fact, this category is expected during normal operation of the program. Must be set on by the generic DAS code when the DAServer starts.
- **DASProtWarn:** Something unexpected occurred in the protocol, for example, a requested item with an otherwise valid item name is not supported by this device. Must be set on by the generic DAS code when the DAServer starts.
- **DASTrace:** General diagnostic messages of a protocol-specific nature. For example, you can provide the number of items in a message for a specific protocol, then optimize based on the number.
- **DASVerbose:** Modifies all other DAS logging flags. When on, provides detailed messages.
- **DASSend:** Protocol messages sent to the device are logged to this category.
- **DASReceive:** Protocol messages received from the device are logged to this category.
- **DASStateCat1, DASStateCat2, DASStateCat3, DASStateCat4:** These are general categories for use by the server developer. As DeviceEngine-generated state machines are created by the DAServer, they can be told to log state machine messages to one of the following: DASStateCat1, DASStateCat2, DASStateCat3, or DASStateCat4. These messages indicate when a state is made the active state, when a state handler is run, when a state handler completes, and when a timeout occurs for a state machine.
- **DASStateMachine:** By default, DeviceEngine-generated state machines created by the DAServer log to this category unless specifically told to log to one of the DASStateCatN categories. In addition, general state machine messages are logged to this category. These messages indicate when a state machine is created and deleted.

Error Message Descriptions

These messages are specific to the Wonderware DAServer for Omron Fins Ethernet. When you enable the specified log flag, these messages are generated and logged.

Message	Log Flag	Possible Cause	Solution
Missing address	Warning	A tag address has no length.	Re-enter the address in the client application.
Device address '<address>' contains a syntax error.	Warning	A tag address contains one or more invalid characters.	Re-enter the address in the client application.
Address '<address>' is out of range for the specified device or register.	Warning	A tag address references a location that is beyond the range of supported locations for the device.	Verify that the address is correct. If the address is incorrect, re-enter it in the client application.
Device address '<address>' is not supported by model '<model name>'.	Warning	A tag address references a location that is valid for the communications protocol but not supported by the target device.	Verify that the address is correct. If the address is incorrect, re-enter it in the client application. Verify that the selected model name for the device is correct.
Data Type '<type>' is not valid for device address '<address>'	Warning	A tag address has been assigned an invalid data type.	Modify the requested data type in the client application.
Device address '<address>' is read-only.	Warning	A tag address has a requested access mode that is not compatible with what the device supports for that address.	Change the access mode in the client application.
Winsock V1.1 or higher must be installed to use the Omron FINS Ethernet device driver	Error	The version number of the Winsock DLL found on your system is less than 1.1.	Upgrade your version of Winsock to 1.1 or higher.

Message	Log Flag	Possible Cause	Solution
Device '<device name>' is not responding.	Error	<ol style="list-style-type: none"> 1. The connection between the device and the host PC is broken. 2. The IP address assigned to the device is incorrect. 3. The named device may have been assigned an incorrect network ID. 	<ol style="list-style-type: none"> 1. Verify the cabling between the PC and the PLC device. 2. Verify that the IP address given to the named device matches that of the actual device. 3. Verify that the network ID given to the named device matches that of the actual device.
Unable to write to '<address>' on device '<device name>'.	Error	<ol style="list-style-type: none"> 1. The connection between the device and the host PC is broken. 2. The named device may have been assigned an incorrect IP address. 3. The named device may have been assigned an incorrect network ID. 	<ol style="list-style-type: none"> 1. Verify the cabling between the PC and the PLC device. 2. Verify that the IP address given to the named device matches that of the actual device. 3. Verify that the network ID given to the named device matches that of the actual device.
Device '<device name>' responded with local node error.	Error	The named device may have been assigned an incorrect network ID.	Verify that the network ID given to the named device matches that of the actual device.
Device '<device name>' responded with destination node error.	Error	The named device may have been assigned an incorrect network ID.	Verify that the network ID given to the named device matches that of the actual device.
Device '<device name>' responded with a communications error.	Error	The named device may have been assigned an incorrect network ID.	Verify that the network ID given to the named device matches that of the actual device.

Message	Log Flag	Possible Cause	Solution
Device '<device name>' cannot process command (Tag '<address>', Size '<bytes>').	Warning	Named device cannot process command for specified model.	Verify that the correct model number is assigned to the device.
Device '<device name>' responded with routing table error.	Error	The named device may have been assigned an incorrect network ID.	Verify that the network ID given to the named device matches that of the actual device.
Device '<device name>' responded with a command format error (Tag '<address>', Size '<bytes>').	Warning	<ol style="list-style-type: none"> 1. The local node's relay table or relay node's local network table is wrong. 2. Incorrect command format has been used. 	<ol style="list-style-type: none"> 1. Verify routing table settings in the network devices. 2. Verify that the correct model number is assigned to the device.
Device '<device name>' responded with a command parameter error (Tag '<address>', Size '<bytes>').	Warning	Requested memory code area is not available.	Check for availability of the referenced address (i.e. existence of Expansion Data Memory).
Device '<device name>' responded with error in unit.	Error	CPU bus error or memory error in named device.	Check the unit for error indicator and attempt to clear errors.
Device '<device name>' cannot accept command (Tag '<address>', Size '<bytes>').	Warning	Too many commands are at the destination node.	Wait for servicing to complete and re-execute command.
Device '<device name>' access right denied (Tag '<address>').	Warning	The access right is held by another device.	Release access right and re-execute command.

Message	Log Flag	Possible Cause	Solution
Device '<device name>' responded with write not possible (Tag '<address>', Size '<bytes>').	Warning	Referenced address is read only or write protected.	Check for write access of referenced address.
Device '<device name>' responded with error '<error code>' (Tag '<address>', Size '<bytes>').	Warning	Non-trappable error code received from device.	Check Omron FINS communication protocol manual for error information.
Unable to bind to adapter: '<adapter>'. Connect failed.	Warning	Two or more devices, in different channels, are using the same source IP address and port number.	Because of the IP binding requirement of FINS, each channel must have a unique source IP address. To accomplish this, the host computer must have a separate network interface card for each channel, or you must design your application so that a single channel is used.
Device '<device name>' deactivated due to network settings conflict with device '<device name>'.	Error	The network parameters for the stated device were changed during run time, and were found to be in conflict with another device.	Communication with this device is not be possible until the conflict is resolved. Change one or more of the following: channel network adapter, port number, or device ID.

Message	Log Flag	Possible Cause	Solution
Unable to write to register <register address> for device <device name>. The device is in run mode.	Warning	The device is in run mode. CS and TS registers can only be written to when the device is in programming mode.	Set the device to programming mode.

Index

Symbols

\$SYS\$Status 50

Numerics

32-bit values, using 63

A

activate 44
 adapter 19
 address descriptions 64
 array support 63

B

BCD support 60
 bit access 63

C

C200 address descriptions 64
 channel
 adding 18
 deleting 21
 renaming 18
 setting parameters 18
 CJ1 address descriptions 101
 communication timeouts 26
 connect timeout 26
 fail after 26
 reply timeout 26

communications port 19
 configuration sets
 archiving 43
 changing parameters 43
 clearing 44
 deleting 44
 selecting 43
 configure
 as a service 42
 not a service 42
 Connect timeout 26
 CS1 address descriptions 95
 CV1000 address descriptions 74
 CV2000 address descriptions 74
 CV500 address descriptions 70
 CVM1-CPU01 address descriptions 80
 CVM1-CPU11 address descriptions 84
 CVM1-CPU21 address descriptions 88

D

DAServer Manager 9, 15
 troubleshooting 108
 DASReceive 111
 DASSend 111
 data types
 definition 59
 supported 58
 DDE/SuiteLink

- \$SYS\$STATUS 50
 - accessing data using 48
 - configure as a service 42
 - device groups 31
 - topic 48
- deactivate 45
- demo mode 46
- device groups 31, 49
 - adding 31
 - deleting 34
 - renaming 32
 - setting data 33
 - update interval 33
- device items 35
 - clearing all 39
 - definition 35
 - deleting 37
 - renaming 37
 - setting the name 36
- devices
 - adding 23
 - deleting 30
 - renaming 24
 - setting options 27
 - setting parameters 24
 - setting the model 24
- duty cycle 20

E

- error descriptions 112
- error log flag 109
- export 38

F

- fail after 26
- FINS
 - network configuration 28
- firewall 12
- floating point format support 60

I

- importing 39
- in-proc 45
- item reference 35
 - access 59
 - data type 59
 - device type 59
 - format and syntax 59

- memory access 60
- range 59
- setting 38
- supported data types 58

L

- Log Flag Editor 108
- log flags 108
 - DASReceive 111
 - DASSend 111
 - error 109
 - warning 109
- Log Viewer 10
- long format support 60

O

- OPC
 - \$SYS\$STATUS 50
 - accessing data using 48
 - browsable items 35
 - device groups 31
 - supported protocols 10
- out-of-proc 45

P

- ports
 - setting 19

R

- reply timeout 26
- request size, setting 27

S

- service
 - configuring as 42
 - configuring not as a 42
- string support 61
- SuiteLink
 - address fields 48
 - supported protocols 10
- system items 10, 35, 49

T

- time out 26
- troubleshooting 10, 107, 108
 - Log Flag Editor 108
 - Log Viewer 108
 - version information 108

U

update interval 31, 33

V

version information 108

W

warning log flag 109

