

SONY

2-638-316-01(1)

ERS-7M2

for AIBO MIND 2



## 「ダンサー機能」追加のご案内

2005年5月より、「AIBO マインド2」に新たに「ダンサー機能」を追加いたしました。ダンサー機能は、AIBOに音楽を聞かせると音の大きさやリズムに合わせて、AIBOがさまざまなダンスを披露してくれる機能です。あなたのお気に入りの音楽を聞かせて、楽しくダンスするAIBOをお楽しみください。

### ご注意

- AIBO本体の取り扱いや操作方法については、別冊の「ユーザーガイド基本編」をご覧ください。
- ダンサー機能で動作中は、ピンクボールやアイボーン、あなたのお顔、お気に入りのもの、AIBOカードには反応しません。
- バッテリーの残りが少なくなっても自己充電しません。
- ダンサー機能はステーション上でも動作しますが、ダンサー機能で動作中に、ステーションに載せたり降ろしたりすると、ダンサー機能が解除されます。
- 生まれたばかりのときは、ダンサー機能は動作しません。

## ダンサー機能の遊びかた

- 1 自律モードのAIBOに、「**りずむにのって**」または「**りずむにあわせて**」と話しかける  
AIBOの頭ランプがオレンジに点滅します。
- 2 頭タッチセンサーを触るか、もう一度「**りずむにのって**」または「**りずむにあわせて**」と話しかける  
モードランプが順番に6色に光ります(ダンサー機能で動作している間は、モードランプが6色に光ります)。
- 3 AIBOに**あなたの好きな音楽を聞かせる**  
AIBOがリズムをとりながら、音楽に合わせてダンスを始めます。

### 💡ヒント

- 曲によっては、うまくダンスができないことがあります。
- ダンサー機能で動作中に30分以上そのままにしておくと、AIBOはダンスをやめてしまいます(モードランプは6色に光っています)。このようなときは、背中タッチセンサーまたは頭タッチセンサーを触ると、またダンスを始めます。

## ダンサー機能を終了したいときは

頭タッチセンサーを3秒以上触るか、あごセンサーを触ります。



\* 2 6 3 8 3 1 6 0 1 \* (1)

SONY

ERS-7M2

for AIBO MIND 2



## Introducing the New “Dancer Function”

In May 2005, the new “Dancer function” was added to the “AIBO MIND 2” software.

When you play music for the AIBO® Entertainment Robot ERS-7, it performs various dances in sync with the rhythm and volume of the music. Try playing your favorite music and enjoy watching how the AIBO robot dances around happily.

### Notes

- For more on handling and operating the AIBO robot, refer to the separate “User’s Guide (Basic).”
- When operating under the Dancer function, the AIBO robot does not respond to the pink ball, the AIBOne toy, your face, your favorite things, or AIBO cards.
- The AIBO robot does not charge automatically, even if its remaining battery power is low.
- The Dancer function can also operate while the AIBO robot is on the Energy Station. But when the AIBO robot is taken off or placed on the Energy Station, the Dancer function turns off.
- In the puppy stage, the Dancer function cannot be used.

## How to Enjoy the Dancer Function

- 1** Say “*Feel the rhythm*” or “*Feel the music*” while the AIBO robot is in Autonomous mode.  
The AIBO robot’s head light begins to flash orange.
- 2** Touch the head sensor, or say “*Feel the rhythm*” or “*Feel the music*” again.  
The mode indicators turn each of the six colors in order. (While the Dancer function is operating, the mode indicators continue to turn each of the six colors.)
- 3** Play your favorite music.  
The AIBO robot begins keeping the rhythm and dancing in time to the music.



### Hints

- The AIBO robot may not be able to dance well to certain types of music.
- If you leave the AIBO robot operating under the Dancer function for 30 minutes or more, the AIBO robot stops dancing (but the mode indicators continue to turn each of the six colors). When this happens, touch the back sensor or head sensor to make the AIBO robot begin dancing again.

## To Turn Off the Dancer Function

Touch the head sensor for at least 3 seconds, or touch the chin sensor.