



Dual Language Operating System Selection

Your Sony VAIO computer is equipped with the **Dual Language Operating System Selection**.

This means that you can choose between two languages.

The option is made available the first time your Sony VAIO computer is started.

Language 1: Dutch is already preinstalled on the computer, and requires only a quick activation.

Language 2: English requires a full installation using the English VAIO Recovery and Documentation Disc included in the package.

It is entirely up to you which language to decide to use.

But you must be aware that **this is a one-time, irreversible decision**.

If you select language 1, you cannot switch to language 2, or vice versa.

It is therefore extremely important that you are sure of your choice before you proceed with the installation.

To choose the system language on your computer, proceed as follows:

- 1 Turn on your Sony VAIO computer.
- 2 Read the warning message on the screen and select either language 1 or 2.
- 3 Read the second warning and confirm your language choice.
- 4 Read the confirmation message and type your choice again only if you are absolutely sure that you want to proceed with the installation.
 - If you choose Dutch, the computer will restart automatically with Dutch as the system language,or
 - If you choose English, you will be asked to insert the appropriate VAIO Recovery and Documentation Disc to install the language.
Once the recovery procedure is completed, the computer will restart automatically with English as the system language.

Read the information and follow the instructions onscreen to complete the procedure and further configure your machine.

 The installation procedure for English can last up to 60 minutes.