




CD/DVD prehrávač

DVP-SR160


(SK) Prehľad pri prvom spustení

1


A




■ SCART



B






■ COAXIAL





* Nedodávané

2



3



TIME/TEXT

PICTURE NAVI

1	2	3
4	5	6
7	8	9

AUDIO

1: ENGLISH DOLBY DIGITAL 3/2.1

SUBTITLE

1: ENGLISH

A mountain towers over a lake.

MENU

CHAPTER

Chapter 1	Chapter 2	Chapter 3
Chapter 4	Chapter 5	Chapter 6

DISPLAY

1 (1)
1 (12)
T 0:00:00

DVD VIDEO

TITLE

ENTER Quit: DISPLAY

Diagram showing playback progress bars with a person icon representing the current position.