



START


SRS-XB20

4-693-259-11(1)
©2017 Sony Corporation




* 4 6 9 3 2 5 9 1 1 * (1)




1




DC IN 5V






CHARGE ⏱ 12 h : 00 m (500mA) CHARGE
 ⏱ 04 h : 00 m (1.5A)







2




ON PAIRING 3s





Android iPhone



3





⏸ ⏪ ⏩





⏪ ⏩ 🔊







⏸ x3 ⏪ x2 ⏩ x2



Kryetari shto



Pa tel Party Chain



Android / iPhone

SongPal

<http://sonyapp.jp/songpal.html>

i

http://rd1.sony.net/help/speaker/srs-xb20/h_zz/