



START



SRS-XB30

4-693-384-11(1)  
©2017 Sony Corporation




\* 4 6 9 3 3 8 4 1 1 \* (1)




# 1




# 2





# 3







Referenca Udhëzuesi



**Kryetari shto**



**Pa tel Party Chain**



**Android / iPhone**

**SongPal**

<http://sonyapp.jp/songpal.html>

**i**

[http://rd1.sony.net/help/speaker/srs-xb30/h\\_zz/](http://rd1.sony.net/help/speaker/srs-xb30/h_zz/)